

Hybrid Hydraulic System

# Super Unit (Analog Model) with Flow Switching Function

[200V]SUT00D8021-30-B-N0323

[400V]SUT00D8021-21YB-N0324

[200V]SUT00D13021-10-B-N0321

[400V]SUT00D13021-10YB-N0322

[200V]SUT00D15021-10-B-N0365

[400V]SUT00D15021-10YB-N0358

## Operation Manual (ORIGINAL INSTRUCTIONS)



DAIKIN INDUSTRIES, LTD.

**Oil Hydraulics Division**

# Introduction

Thank you for selecting the SUPER UNIT of DAIKIN Hydraulic System.

This operation manual describes how to operate this SUPER UNIT, and maintenance/inspection, troubleshooting procedure and specifications of this system. Before using this product, be sure to read through this manual carefully to ensure proper use of the system.

## General Precautions

- Improper operation or handling of this product causes an accident, reduced service life or performance deterioration of the equipment.
- For explanation of the system components in detail, some of the figures and pictures given in this manual show the internal components without the cover or safety shield. During actual operation of this system, be sure to mount the cover and safety guard in the original conditions, and follow the operating procedure described in this manual.
- The contents of this manual are subject to change for the purpose of a change in product specifications or improvement of users' convenience.
- Keep this manual carefully in a place where users can refer to it whenever required.
- The figures given in this manual may be different from the conditions of the actual product because of product improvement.

# Contents

Chapter 1	Safety Instructions .....	1-1
1.1	To Ensure Safe Use of the Product .....	1-1
1.1.1	Application of this product .....	1-1
1.1.2	Precautions for using this product.....	1-1
1.1.3	Precautions for transportation.....	1-2
1.1.4	Precautions for installation and wiring .....	1-2
1.1.5	Precautions for operation .....	1-3
1.1.6	Precautions for maintenance and inspection .....	1-3
1.1.7	Precaution for product disposal .....	1-4
1.2	Exemptions from Manufacturer's Responsibility .....	1-4
Chapter 2	Outline .....	2-1
2.1	Outline of this System.....	2-1
Chapter 3	Specifications.....	3-2
3.1	Model Identification Code .....	3-2
3.1.1	Types of motor pump and controller .....	3-2
3.1.2	Manufacturing No. ....	3-3
3.2	Specifications .....	3-4
3.2.1	Power supply voltage specification .....	3-4
3.2.2	Principal specifications .....	3-4
3.2.3	Common specifications of products .....	3-5
3.3	P-Q Characteristics .....	3-7
3.3.1	Typical characteristics .....	3-7
3.4	Pump capacity selection.....	3-10
3.4.1	System Description .....	3-10
3.4.2	Output characteristic.....	3-11
3.5	Precautions for Use .....	3-12
3.6	Outer Dimensions.....	3-13
3.6.1	Motor pump outer dimensions .....	3-13
3.6.2	Controller outer dimensions (All models are the same).....	3-15
Chapter 4	Part Names .....	4-1
4.1	Part Names of Each Unit .....	4-1
4.1.1	Motor pump .....	4-1
4.1.2	Controller (All models are the same) .....	4-3
Chapter 5	Startup Procedure.....	5-1
Chapter 6	Checking the Product on Delivery.....	6-1
6.1	Checking the package contents.....	6-1
6.2	Confirming the product model.....	6-1

Chapter 7	Transportation and Installation.....	7-1
7.1	Transportation.....	7-1
7.1.1	Transportation of the product in package.....	7-1
7.1.2	Transportation of the motor pump.....	7-1
7.2	Installation of Motor Pump.....	7-2
7.2.1	Precautions for installation of the motor pump.....	7-2
7.2.2	Changing direction of the pump suction port.....	7-3
7.3	Installation of the controller.....	7-4
Chapter 8	Hydraulic Piping.....	8-1
8.1	Discharge pipe.....	8-1
8.2	Suction piping.....	8-3
8.3	Drain piping.....	8-4
Chapter 9	Electric Wiring.....	9-1
9.1	Selection of Peripheral Equipment.....	9-1
9.1.1	Breaker.....	9-1
9.2	Optional Electrical Equipment.....	9-1
9.2.1	DC reactor.....	9-1
9.2.2	Regenerative braking resistor.....	9-3
9.2.3	Pressure sensor harness.....	9-3
9.2.4	Encoder harness.....	9-4
9.2.5	Ferrite core.....	9-4
9.2.6	Ring core.....	9-5
9.2.7	Noise filter.....	9-5
9.2.8	Optional accessory set.....	9-7
9.3	Electrical Connection Diagram (Overall).....	9-8
9.4	Terminal Connections.....	9-10
9.4.1	Crimp terminal.....	9-10
9.4.2	Recommended wire.....	9-10
9.4.3	Connections to the controller.....	9-11
9.4.4	Connections to the motor.....	9-13
9.5	Connecting the Power Supply.....	9-14
9.6	Connecting the Motor Cable.....	9-16
9.6.1	Connections to the controller.....	9-16
9.6.2	Connections to the motor.....	9-19
9.7	Connecting the Motor Cooling Fan.....	9-20
9.8	Connecting the Motor Thermistor Harness.....	9-21
9.8.1	Connections to the controller.....	9-21
9.8.2	Connections to the motor.....	9-22
9.9	Connecting the Encoder.....	9-23
9.10	Connecting the Pressure Sensor Harness.....	9-25

9.11	Connecting Peripheral Equipment .....	9-27
9.11.1	Connecting the DC reactor .....	9-27
9.11.2	Connecting the regenerative breaking resistor.....	9-29
9.12	Connecting the I/O Signal Cables.....	9-30
9.12.1	Specifications of I/O signals.....	9-31
Chapter 10	Panel Operations .....	10-1
10.1	Parts Names and Principal Functions of the Operation Panel.....	10-1
10.2	Functions of the Operation Panel .....	10-1
10.2.1	Outline of functions.....	10-1
10.2.2	Shift between individual modes .....	10-2
10.3	Monitor Mode Display.....	10-2
10.3.1	Monitor mode display items.....	10-2
10.3.2	Operation in the monitor mode .....	10-4
10.4	Setting Mode Display.....	10-5
10.4.1	Setting mode display items.....	10-5
10.4.2	Operation in the setting mode.....	10-6
10.5	“H” Mode .....	10-7
10.5.1	“H” mode display items.....	10-7
10.5.2	Operation in the “H” mode .....	10-9
10.6	Alarm Mode Display .....	10-9
10.6.1	Alarm list .....	10-9
10.6.2	Operation in the alarm mode .....	10-10
Chapter 11	Trial Run/Operation .....	11-1
11.1	Running power ON.....	11-1
11.2	Description of Parameters .....	11-1
11.2.1	[P05:VMAX] Input command voltage scaling value .....	11-1
11.2.2	[P06:PMAX], [P07:QMAX] Pressure/flow rate command scaling.....	11-1
11.2.3	[P15:BIAS] Pressure command in standby status .....	11-3
11.2.4	[P00:DI_A] Start/stop signal switching.....	11-3
11.2.5	[P25:BR_R], [P26:BR_W] Regenerative resistor setting .....	11-4
11.2.6	[P29:WN_L] Overload warning output judgment level .....	11-5
11.2.7	[H47 : DI_L] Pump capacity selection signal switching.....	11-5
11.3	Confirmation of linearity of command voltage $P_i/Q_i$ .....	11-6
11.4	Pump Operation/Air Purge.....	11-7
11.5	Management of parameters.....	11-8
Chapter 12	Gain Adjustment .....	12-1
12.1	[P08: P_UG] Pressure Rising Gain .....	12-1
12.2	[P09: P_DG] Pressure Falling Gain.....	12-1
12.3	[P10: Q_UG] Flow Rate Rising Gain .....	12-1

12.4	[P11: Q_DG] Flow Rate Falling Gain.....	12-2
12.5	[P13: SC_G] Surge Pressure Reduction Gain .....	12-2
12.6	[P14: D_TM] Delay time setting .....	12-2
12.7	Pressure Proportional Gain/Integral Time .....	12-3
12.7.1	Control response trace.....	12-3
12.7.2	[P17:P_P1],[P18:P_P2] Pressure Proportional Gain.....	12-4
12.7.3	[P19:P_I1],[P20:P_I2],[P21:P_I3] Pressure Integral Time .....	12-4
12.7.4	[P24:P_SP] Cutoff width.....	12-4
12.8	Pressure Proportional Gain/Integral Time .....	12-5
12.9	Pressure Rising Time Constant/Pressure Falling Time Constant .....	12-5
12.10	Speed Differential Gain.....	12-5
Chapter 13	Autonomous Switching Function.....	13-1
13.1	Autonomous switching setting.....	13-1
13.1.1	Wire for autonomous switching .....	13-1
13.1.2	Change " H54: pump switching condition" .....	13-1
13.2	Additional parameters .....	13-1
13.2.1	Confluence → single switching parameters configuration.....	13-3
13.2.2	Single → confluence switching parameters configuration .....	13-4
13.2.3	Other pump states .....	13-4
13.2.4	Switching logic of the digital output signal .....	13-4
13.2.5	Example of the pump switching adjustment .....	13-5
13.3	Pump confluence / single selection with a digital input signal.....	13-6
Chapter 14	Maintenance and Inspection .....	14-1
14.1	Protective Functions .....	14-1
14.1.1	Description of alarms .....	14-1
14.1.2	Description of warnings.....	14-5
14.1.3	Contact Output at Power-ON .....	14-7
14.1.4	Troubleshooting .....	14-8
14.2	Periodic Inspection.....	14-11
14.3	Cleaning and Replacement.....	14-12
14.3.1	Replacement of oil .....	14-12
14.3.2	Cleaning of motor cooling fan.....	14-12
14.3.3	Replacement of the controller .....	14-12
14.3.4	Replacement of the pressure sensor.....	14-12
14.3.5	Replacement of the pump.....	14-13
Chapter 15	Wiring Diagram .....	15-1

## Chapter 1 Safety Instructions

### 1.1 To Ensure Safe Use of the Product

Before installation, operation or maintenance/inspection of this product, be sure to read through this operation manual and all other attached documents carefully, so that you can thoroughly understand this system, safety information and all other precautions to ensure proper use of this product.

This operation manual classifies safety precautions into the following two levels: “CAUTION” and “WARNING”.

 <b>WARNING</b>	Indicates potentially hazardous conditions that may result in death or serious injury, if the product is improperly handled.
 <b>CAUTION</b>	Indicates potentially hazardous conditions that may result in medium/minor injury or property damage, if the product is improperly handled.

Even a condition classified as “CAUTION” may result in a serious accident, depending on the situation. Since both levels of the safety instructions indicate important information, be sure to observe these instructions.

In addition to the above, “IMPORTANT” means the instructions that must be observed by users, although they do not correspond to “WARNING” or “CAUTION”.

“NOTE” provides information necessary for using this product.

#### 1.1.1 Application of this product

 <b>WARNING</b>
● This product is a hydraulic unit to drive a molding machine installed inside a factory. Do not use this product for any other purpose.

#### 1.1.2 Precautions for using this product

 <b>WARNING</b>
<ul style="list-style-type: none"><li>● Transportation, installation, piping, wiring, operation, manipulation, maintenance and inspection of this product must be conducted by qualified personnel. To conduct such work, wear protective gear required to ensure safe work (work clothes, safety band, helmet, safety shoes, gloves, etc.).</li><li>● Never attempt to modify this product by user. Do not disassemble this product for any purpose other than the inspections specified in this manual. Failure to observe this instruction may result in electric shock, fire or injury.</li><li>● This product has been manufactured under thorough quality control. However, if this product is applied to any equipment where a serious accident or damage can be expected due to a fault of this product, the applicable equipment must be provided with appropriate safety devices.</li><li>● To prevent hazardous conditions of the machine and equipment in case of a fault of this product, provide an emergency brake or other safety measures for the whole system. Failure to observe this instruction may result in injury or other accidents. If any part of the unit body is damaged or missing, do not install or operate this product. Failure to observe this instruction may result in an accident.</li><li>● Use this product within the specification range given in this manual. Failure to observe this instruction may result in an accident or injury.</li></ul>

### 1.1.3 Precautions for transportation

#### **WARNING**

- Before transporting this product, check the weight and the center of gravity of this product. Failure to observe this instruction may result in injury.
- For transportation of the motor pump, use the eyebolts. If this product is slung by any part other than the eyebolts, it may fall or overturn.
- When this product is in the packed condition, transport it with appropriate transportation tools. Otherwise, injury may occur.
- Before operating this product, check if the safety devices can normally work to avoid a hazardous condition in case of malfunction of peripheral sensors and equipment due to electromagnetic noise. Failure to observe this instruction may result in an accident.
- Install this product in a place that can withstand the product weight. Failure to observe this instruction may result in an accident.

#### **CAUTION**

- This product is precision equipment. Be careful not to drop it or apply strong impact to it. Failure to observe this instruction may result in damage to the equipment.

### 1.1.4 Precautions for installation and wiring

#### **WARNING**

- Wiring work must be conducted by qualified technical experts. Failure to observe this instruction may result in electric shock or fire.
- Before conducting wiring work, turn OFF the input power supply. Failure to observe this instruction may result in electric shock.
- To restart wiring work after the power supply is turned ON once, make sure that the motor has stopped, and wait for at least five minutes after the power supply is turned OFF. Failure to observe this instruction may result in electric shock.
- Use a no-fuse breaker or earth leakage breaker conforming to EN60947-2. Failure to observe this instruction may result in electric shock or fire.
- Ground the hydraulic unit according to laws and ordinances of the country where this product is used. Failure to observe this instruction may result in electric shock or fire.
- Be careful not to allow a conductive foreign object (screw, metal chip, etc.) or flammable foreign object (wood chip, oil, etc.) to enter the controller. Failure to observe this instruction may result in electric shock, fire or other accidents.
- Never use this product in a place where it may be splashed with water, or in a place with corrosive or flammable gas atmosphere, or near a combustible material. Failure to observe this instruction may result in electric shock or fire.
- Do not allow damage or strong force to the harness. Do not put a heavy object on it, or pinch or bend it forcefully. Failure to observe this instruction may result in electric shock or damage.
- Do not step on the product, or put a heavy object on it. Failure to observe this instruction may result in electric shock, damage or other accidents.
- Make sure that the power supply input voltage conforms to the specified voltage rating. Failure to observe this instruction may result in fire or other accidents.
- Be sure to observe the specified mounting environment. Failure to observe this instruction may result in fire or other accidents.

 **CAUTION**

- To ensure correct wiring, check the terminal assignment and terminal symbols.
- Conduct withstand voltage test at 2120 VDC or lower voltage. Otherwise, the hydraulic unit may be damaged.
- Conduct megger test according to laws and ordinances of the country where this product is used.
- Do not apply strong impact to this product. Failure to observe this instruction may result in a fault of the product.
- Make sure that the ambient temperature/humidity is within the allowable temperature/humidity range of this product. Failure to observe this instruction may result in a fault or shortened service life of this product.
- For the hydraulic unit of 400 V type, ground the neutral point of the power supply. Otherwise, the hydraulic unit may be damaged.
- Use a commercial power supply. If other power supply (inverter power supply etc.) is used, the hydraulic unit may be damaged.

## 1.1.5 Precautions for operation

 **WARNING**

- Do not operate any switch with a wet hand. Failure to observe this instruction may result in electric shock.
- When the power supply is ON, do not change the wiring, or connect/disconnect a terminal. Failure to observe this instruction may result in electric shock, damage or other accidents.

 **CAUTION**

- Specify the pressure command and velocity command so that the command values do not exceed the allowable pressure and velocity ranges of the machine. Failure to observe this instruction may result in an accident.
- Before operating the system, specify the parameters according to the machine being used. Failure to observe this instruction may result in injury or the failed machine.
- If a power failure occurs, set up the equipment so that the hydraulic unit will not abruptly restart after power recovery. Failure to observe this instruction may result in injury.
- During operation, and immediately after operation, do not touch the radiator fins and electronic equipment because these parts are hot. Failure to observe this instruction may result in burns.
- Do not turn ON/OFF the power supply frequently. Failure to observe this instruction may result in a fault of the equipment.

## 1.1.6 Precautions for maintenance and inspection

 **WARNING**

- Maintenance and inspection must be conducted by qualified technical experts. Failure to observe this instruction may result in electric shock or injury.
- Before maintenance or inspection, make sure that the input power supply is OFF. Failure to observe this instruction may result in electric shock.
- Before maintenance or inspection, make sure that the motor has stopped, and wait for at least five minutes after the power supply is turned OFF. Failure to observe this instruction may result in electric shock.

### 1.1.7 Precaution for product disposal



- Dispose of this product according to laws and ordinances of the country where this product is used.

## 1.2 Exemptions from Manufacturer's Responsibility

- DAIKIN shall not be responsible for any damage attributable to a fire, earthquake, third party's action or other accident, or user's intentional or unintentional failure, improper use or use of the product under other abnormal conditions.
- DAIKIN shall not be responsible for any incidental damage attributable to use or impossibility of use of this product (e.g. loss of business profit or interruption of business operations).
- DAIKIN shall not be responsible for any accident or damage attributable to a failure to observe the instructions given in this manual or supply specifications.
- DAIKIN shall not be responsible for any damage attributable to malfunction caused by combination with other equipment.
- DAIKIN shall not be responsible for any accident or damage attributable to disassembly or modification of the product made by the user.

## Chapter 2 Outline

### 2.1 Outline of this System

This product is a hydraulic unit intended for molding machine manufacturers to drive a molding machine installed inside a factory. This hydraulic unit mainly consists of an IPM motor, gear pump, pressure sensors and digital controller. It incorporates pressure and flow rate control functions through motor rotation speed control.

When this hydraulic unit is mounted to a molding machine in combination with a directional selector valve, operation speed and hold pressure can be easily controlled in die clamping, weighing and injection steps. Pressure and flow rate control commands are input as analog voltages from the molding machine. During cylinder operation, the hydraulic unit executes flow rate control. After the cylinder load pressure exceeds a command pressure, the hydraulic unit executes pressure control by reducing the motor rotation speed so that a target pressure is not exceeded.


During flow rate control, a pump motor rotation speed is detected with an encoder. During pressure control, pump discharge pressure is detected with a pressure sensor for feedback control. The IPM motor is always controlled so as to provide a rotation speed and torque just required for the molding machine. This hydraulic unit ensures overwhelmingly higher energy-saving effect and higher control performance, in comparison with conventional hydraulic control systems using flow rate control valves and pressure control valves.

## Chapter 3 Specifications

### 3.1 Model Identification Code


#### 3.1.1 Types of motor pump and controller

**SUT 00 D 80 21 - 21 Y B - \* \* \* \* \***




Product type	Non-standard content
SUT00D8021-30-B-N0323	Suction flange 0-10V analog input specifications
SUT00D8021-21YB-N0324	
SUT00D13021-10-B-N0321	
SUT00D13021-10YB-N0322	
SUT00D15021-10-B-N0365	
SUT00D15021-10YB-N0358	

3.1.2 Manufacturing No.



• Example of nameplate




[RATED CURRENT]

Average operating current at specified maximum output

[MAX CURRENT]

Maximum static current of short-time operation rating



**NOTE**

Before shipment, a pair of motor pump and controller has undergone inspection. Use the pair of motor pump and controller of the same serial No. The serial No. is indicated on the nameplate of each product.

## 3.2 Specifications

### 3.2.1 Power supply voltage specification

Please note that the product specification will be different by different power supply voltage specification. If the "Y" is included in the product form, it is 400V models, otherwise it is 200V models.

	200V Models	400V Models
Controller power supply	AC 3φ 200~220V (50Hz/60Hz) Allowable power supply voltage fluctuation range -15%~+10%	AC 3φ 380~440V (50Hz/60Hz) Allowable power supply voltage fluctuation range -20%~+10%
Motor cooling fan power	AC 1φ 200V (50Hz/60Hz)	AC 1φ 230V (50Hz/60Hz)

### 3.2.2 Principal specifications

Item		Specification					
Model Identification Code		SUT00D					
		8021		13021		15021	
		200V	400V	200V	400V	200V	400V
Confluence	Maximum operating pressure (MPa)	17.6		20.6		17.6	
	Maximum flow rate (L/min)	80		130		150	
Single	Maximum operating pressure (MPa)	20.6					
	Maximum flow rate (L/min)	38.5		47.9		70.9	
Operating pressure adjusting range (MPa)		0.21~20.6					
Operating flow rate adjusting range (L/min)		0.8~80.0		1.3~130.0		1.5~150.0	
Pump	Pump type	Double gear pump					
	Pump capacity (cm <sup>3</sup> /rev)	16.2-15.0		27.8-16.2		27.8-24.9	
Rated point		1800min <sup>-1</sup> 58.4N·m		1800min <sup>-1</sup> 79.6N·m		1800min <sup>-1</sup> 117N·m	
	Rated current for controller input (A)	36	19	51	26	51	26
	Rated current for motor input (A)	39	21	61	29	61	29
Power capacity (kVA)		23.8	20.1	33.8	34.8	33.8	34.8
Weight	Motor pump (kg)	76		109			
	Controller (kg)	10					
Applied standards (*1) EMC Directive		IEC/EN55011,IEC/EN61000-6-2,IEC/EN61800-3					

\*1. DAIKIN-recommended noise suppressing measures may be required depending on the operating environment of your unit. Please refer to "9.2.7 Noise filter".

## 3.2.3 Common specifications of products

Item		Specification	
Analog input	(2ch)	Command resolution 0.1% of F.S.	
	Pressure command Pi	0 – +10V / 0 – P <sub>MAX</sub> (*1)	
	Flow rate command Qi	0 – +10V / 0 – Q <sub>MAX</sub> (*1)	
Analog output	(2ch)		
	Pressure monitor Po	0 – +10 V / 0 – P <sub>MAX</sub> (*1)	
	Flow rate monitor Qo	–10 – +10 V / –Q <sub>MAX</sub> – +Q <sub>MAX</sub> (*1)	
Digital input signal (*2)	(8ch)	Insulated via photo-coupler, +24 VDC (27 V max.), 5 mA/ch Positive common/Negative common	
	DI1	Start/stop signal	
	DI5	Pump capacity selection signal	
	DIN2–8	(Unused)	
Digital output signal (*3)	(7ch)	Insulated via photo-coupler, +24 VDC, 30 mA max. Negative common	
	DO1	Ready signal	
	DO2–3	(Unused)	
	DO4	Warning output (Normal: OFF, Warning: ON)	
	DO5–7	(Unused)	
Contact output	(1ch)	Dry contact, 30 VDC, 1c contact, 500 mA max.	
Drive motor		3-phase IPM motor	
Paint color	Motor pump	No painting, Fan cover: Black	
	Controller	Ivory white (Munsell 5Y7.5/1)	
Hydraulic oil (*4)	Oil type	Dedicated mineral hydraulic oil, Wear-resistant hydraulic oil	
	Oil temperature	0–60°C (Recommended temperature range: 15–50°C)	
	Viscosity grade	ISO VG32–68	
	Viscosity range	15–400 mm <sup>2</sup> /s	
	Pollution degree	NAS Class 9 or lower degree	
Operating environment	Atmosphere	Indoor (Not exposed to direct sunlight) Free from corrosive gas, inflammable gas, oil mist and dust	
	Altitude	1000 m max.	
	Ambient humidity	85%RH or less (No condensation)	
	Ambient temperature	Motor pump	0–40°C
		Controller	0–55°C
	Installation direction	Motor pump	To be fastened to molding machine base. Horizontal installation
		Controller	To be mounted in control panel (IP54). Vertical installation (with the main power supply terminal block facing down)
	Protective structure	Controller	IP00
Motor (*5)		IP44	
Storing environment	Storing temperature	Motor pump	–20 to 70°C (No freezing)
		Controller	–20 to 60°C (No freezing)
		Storing humidity	
	Motor pump	85%RH max. (No condensation)	
	Controller		
Startup time		5 seconds max. (at 15°C ambient temperature)	
Power supply ground type (*6)		TN	

Item	Specification
Others	<ul style="list-style-type: none"> <li>• Be sure to connect a no-fuse breaker to the controller power supply. For the no-fuse breaker, refer to “9.1.1 Breaker”.</li> <li>• Be sure to connect the ground terminals of the controller and the motor pump</li> <li>• If the controller power supply is frequently turned ON/OFF, the controller service life will be remarkably shortened. It is recommended that the motor should be started and stopped with digital input (DI1).</li> </ul>

- \*1. For details of PMAX and QMAX, refer to “11.2.2 [P06:PMAX], [P07:QMAX] Pressure/flow rate command scaling”. Input/output voltage can be changed with the “VMAX” parameter. For the “VMAX” parameter, refer to “11.2.1 [P05:VMAX] Input command voltage scaling value”.
- \*2. To use a semiconductor relay, select a relay whose leak current is 1 mA or less.
- \*3. To use a relay, provide surge-suppressing measures, or select a surge-protective type.
- \*4. A hydraulic oil other than mineral hydraulic oil (water-containing oil or synthetic oil: e.g. water-glycol) cannot be used. When the hydraulic oil is used at a temperature out of the recommended operating temperature range, the pressure pulsation may increase, or the flow rate may decrease. However, it is not an abnormal condition. For recommended brands of hydraulic oil, refer to DAIKIN “Hydraulic Unit General Catalog” (Reference No. HK196).”
- \*5. Except for the shaft through hole, encoder connector, motor cooling fan and terminal box.
- \*6. TN-C: TN type grounding that uses both neutral line and protective conductor. TN-S: TN type grounding that separates neutral line from protective conductor. The TN type power distribution system provides a protective ground conductor together with a power line, so that the power supply system is grounded via one point, to which point a ground terminal of equipment is to be connected.

**3.3 P-Q Characteristics**

**3.3.1 Typical characteristics**


If a square mean value of average hydraulic output and load pressure is within the range of continuous operation rating for an operation cycle of the molding machine to which this hydraulic unit is mounted, continuous operation is enabled.

The short-time output can be used during an operation cycle of 20% or less duty time ratio. If operation load exceeds this range, the hydraulic unit outputs an overload alarm (“E27” or “E17”) to stop the pump.

Therefore, you should thoroughly consider the load condition and operation cycle of the molding machine to which this hydraulic unit is mounted.

● SUT00D8021-30-B-N0323

**P-Q characteristics (Typical)**




Continuous operation rating:  
3.1 kW  
Short-time operation rating:  
14.0 kW

\* The above data indicate typical characteristics at 40°C oil temperature, with 400 V, 50 Hz power supply.

● SUT00D8021-21YB-N0324

**P-Q characteristics (Typical)**




Continuous operation rating:  
7.4 kW  
Short-time operation rating:  
14.0 kW

\* The above data indicate typical characteristics at 40°C oil temperature, with 400 V, 50 Hz power supply.

● SUT00D13021-10-B-N0321

**P-Q characteristics (Typical)**




Continuous operation rating:  
5.9kW  
Short-time operation rating:  
22.5 kW

\* The above data indicate typical characteristics at 40°C oil temperature, with 400 V, 50 Hz power supply.

● SUT00D13021-10YB-N0322

**P-Q characteristics (Typical)**




Continuous operation rating:  
11.9 kW  
Short-time operation rating:  
22.5 kW

\* The above data indicate typical characteristics at 40°C oil temperature, with 400 V, 50 Hz power supply.

● SUT00D15021-10-B-N0365

**P-Q characteristics (Typical)**




Continuous operation rating:  
5.9 kW  
Short-time operation rating:  
22.5 kW

\* The above data indicate typical characteristics at 40°C oil temperature, with 400 V, 50 Hz power supply.

● SUT00D15021-10YB-N0358

**P-Q characteristics (Typical)**



Continuous operation rating:  
11.9 kW  
Short-time operation rating:  
22.5 kW


\* The above data indicate typical characteristics at 40°C oil temperature, with 400 V, 50 Hz power supply.

### 3.4 Pump capacity selection

#### 3.4.1 System Description

This product allows you to switch the maximum flow rate / maximum pressure by merging the PL and PH discharge ports together or unload the PL through the pump capacity selection block. By inputting the pump capacity selection signal to the controller from the main machine, the PQ characteristics in accordance with the pump state can be chosen.

Please refer to "9.12 Connecting the I/O Signal Cables" and "11.2.7 [H47: DI\_L] pump capacity selection signal switch".



**Note**

Please ensure the pump capacity selection signal is input to the controller. If this signal is not input correctly, the following malfunction will occur.

[Though in confluence state, the controller considers it is in single state]

The reproducibility of the action that motor and controller reach the maximum output in the horsepower curve will be reduced. The pressure will become unstable and the torque will be insufficient, if 8.5V or more pressure command is input at the pressure control state.





[Though in single state, the controller considers it is in confluence state]

Pressure cannot exceed the confluence maximum pressure at the pressure control state. The output of the horsepower curve is less than the maximum output.

### 3.4.2 Output characteristic

The output characteristics of flow rate, pressure, output voltage are shown in the following.

※ In the case of SUT00D8021



### 3.5 Precautions for Use

- This hydraulic unit is equipped with a safety valve. Please adjust the setting pressure. Please set the setting pressure to "maximum working pressure +2 MPa".
- The allowable fluctuation range of the controller power supply voltage is -15 to +10% (200V), -20 to +10% (400V). Even if the power supply voltage is within the allowable range, a power supply voltage fluctuation in the positive direction may result in an alarm output (regenerative overload etc.) during response, depending on the operating condition and load condition of the molding machine, causing the pump to stop.
- If the load volume is large (exceeding the volume given in the table below), please install a check valve for protection. Excessive regenerative power is generated when the controller power supply is turned OFF in high-pressure holding status, which may result in damage to the controller.  
However, if an inline check valve is installed in the pump discharge side, it will not be able to control the pressure on the load side when it decreases. It is necessary to design a pressure relief circuit if you want to use the inline check valve.

	SUT00D8021	SUT00D13021	SUT00D15021
Load volume	10L		
Recommended orifice diameter	φ2.3 or less		

- If load is applied to the pump when the power is being turned on, there is a possibility that the motor does not start properly. Please do not apply load to the pump for 5 seconds after power-on.
- The regenerative braking resistor surface temperature becomes high depending on operating conditions. Mount the regenerative resistor to a metal surface in a well-ventilated place that ensures easy heat radiation. Be careful not to touch the regenerative braking resistor when it becomes hot.
- Install the controller in a control panel that provides IP54 enclosure rating, with at least 100 mm space above and under the controller. To access the controller during wiring, it is recommended that at least 30 mm space is provided on the left side of the controller. Also, ensure at least 100 mm space around the motor pump.
- To protect the hydraulic unit, provide a surge protector near the controller power supply.
- To start and stop the hydraulic unit, use the start and stop signals of the unit, without using an electromagnetic contactor. To turn ON/OFF the electromagnetic contactor, make sure that the hydraulic unit has completely stopped. Otherwise, the power supply circuit devices may be damaged.
- Be sure to connect the neutral point of the power supply to a ground line. If the insulation distance is too short, it may cause a failure of the hydraulic unit.
- Use a commercial power supply. If other power supply (inverter power supply etc.) is used, the hydraulic unit may be damaged.
- You must install filters in the suction side and the tank return line in this product. Please attach the suction filter of 150 mesh to the suction side, and attach the return filter of 10μm to the tank return line.

[Flow switching function model]

Although it is possible to keep the continuous holding pressure at 20.6MPa at single mode, if the pressure holding time exceeds more than 3 minutes, please provide a bleed-off circuit to P line for pump cooling. Please set the pump capacity to 150min<sup>-1</sup> for the bleed-off flow rate.

(For example) In the case of SUT00D8021  $15\text{cc/rev} \times 150\text{min}^{-1} = 2.25\text{L/min}$  (or more)


When the pressure drops, the pump will reverse. The reversing rotation is limited to 300 min<sup>-1</sup> for pump protection. Please set the other circuit for pressure release or high-speed pressure drops.

### 3.6 Outer Dimensions





#### 3.6.1 Motor pump outer dimensions

Secure an installation space in consideration of the surrounding space as shown in “7.2 Installation of Motor Pump”.

- SUT00D8021 (200V, 400V Common)




● SUT00D13021 / SUT00D15021 (200V, 400V Common)



	A	B	C	D	E
SUT00D13021	169	131	220	806	103
SUT00D15021	177	139	228	815	110

### 3.6.2 Controller outer dimensions (All models are the same)

Secure an installation space in consideration of the surrounding space as shown in “7.3 Installation of the controller”.






# Chapter 4 Part Names


## 4.1 Part Names of Each Unit

### 4.1.1 Motor pump


- SUT00D8021 (200V, 400V Common)




● SUT00D13021 / SUT00D15021 (200V, 400V Common)



4.1.2 Controller (All models are the same)



\* Please use a wire with 10 mm<sup>2</sup> or larger cross-section area, or two wires to ground the controller.





## Chapter 5 Startup Procedure

The start-up procedure for this product is as follows:

- 1. Checking** Refer to “Chapter 6 Checking the Product on Delivery”.  
Check the package contents and the product model.
- 2. Installation** Refer to “Chapter 7 Transportation and Installation”.  
After installation is completed, conduct piping work.
- 3. Piping** Refer to “Chapter 8 Piping”.  
After installation is completed, conduct wiring work.
- 4. Wiring** Refer to “Chapter 9 Electric Wiring”.
- 5. Turning Power ON** Refer to “Chapter 11 Test Run”.  
Before turning ON the power supply, be sure to check the following items:

  - Check if the hydraulic unit is properly installed.
  - Check if the piping is properly connected.
  - Check if the hydraulic oil is filled.
  - Check if the cables are properly connected.
  - Check if the digital input signal is OFF. (= Check if the signal from the host device is OFF.)
  - Check if the power supply voltage is proper.
- 6. Setting Parameters** Refer to “11.2 Description of Parameters”.  
After the power supply is turned ON, you can set up the parameters. Set up the pressure, flow rate and other parameters.
- 7. Flushing** Refer to “11.4 Pump Operation/Air ”.  
Execute flushing. To execute flushing, connect all pipes (except for the actuator piping) in a loop, and flush the unit through the filter. During flushing operation, check for a loose pipe or oil leak.
- 8. Replacement with New Oil** Refer to “11.4 Pump Operation/Air ”.  
After flushing is completed, replace the hydraulic oil.
- 9. Air Purge** Refer to “11.4 Pump Operation/Air ”.  
Release air from the hydraulic circuit completely. Incomplete air purge may cause actuator malfunction or abnormal sound from the pump or valve.
- 10. Operation check**  
Operate the hydraulic unit with the signal from a host device, and check the actuator operation.



## Chapter 6 Checking the Product on Delivery

### 6.1 Checking the package contents



- Before unpacking the product, confirm the top and bottom of the product. Otherwise, the product may fall or overturn.

After unpacking the product, make sure that the following items are included:

Pump & Motor	1 unit
Controller	1 unit

### 6.2 Confirming the product model



- Check the product nameplate to confirm that the delivered product conforms to your ordered model. Using an improper product causes damage.

Check the product nameplate to confirm that the delivered product conforms to your ordered model. For product models, refer to “3.1 Model Identification Code”.




**Chapter 7 Transportation and Installation**

**7.1 Transportation**

**7.1.1 Transportation of the product in package**

To transport this product in package, sling the product package with a lift and so on. For sling points, see the figure below. The weight of the product in package is indicated on the label affixed to the side of the package.



**⚠ WARNING**

- To transport this product in package, use an appropriate transportation apparatus. Otherwise, the product may fall or overturn.
- Before lifting the product, check the weight and center of gravity of the product. Otherwise, the product may fall or overturn.

**7.1.2 Transportation of the motor pump**

The motor pump weight is as follows: Sling the motor pump within the sling gear’s rated load capacity.

Unit model	Motor pump weight
SUT00D8021	76[kg]
SUT00D13021/SUT00D15021	109[kg]

**⚠ WARNING**


- For transportation of this product, use the eyebolts attached to the product. If the product is slung by any other parts, the product may fall or overturn.
- Use a transportation apparatus appropriate for this product. Otherwise, the product may fall or overturn.
- Before slinging the product, check the weight and the center of gravity of this product. Otherwise, the product may fall or overturn. For the center of gravity of the single unit of the motor pump, refer to “3.6.1 Motor pump outer dimensions”.

## 7.2 Installation of Motor Pump

### 7.2.1 Precautions for installation of the motor pump

The motor cooling fan sucks up air from outside, and exhausts air toward the motor.

During installation of the motor pump, ensure at least 100 mm space from the motor pump end surface, so that air intake and exhaust of the motor cooling fan will not be blocked. Also, install the motor pump in a well-ventilated place, so that hot air will not stay around the motor pump.



Since the motor pump may slide due to reaction force of the hydraulic oil in the piping, or due to a shock during startup, fasten the motor pump horizontally to a molding machine base. The recommended mounting bolt is M12.

When the motor pump is installed as shown above, ensure ventilation around the exhaust port. (For example, use a cover with ventilation holes.)

If the motor pump and installation base are mounted with shock-absorbing rubber, the motor pump may shake during motor startup, and when reaction force of hydraulic oil is applied to the pump. Ensure an enough space with a margin in consideration of vibration of the piping.

### CAUTION

- Do not drop this product, or do not apply strong impact to this product. Failure to observe this instruction may result in an accident or damage to the product.
- Do not step on this product, or do not put a heavy object on the product. Failure to observe this instruction may result in an accident or damage to the product.
- Fasten this product securely. Tighten the mounting bolts securely so that they will not be loosened by vibration. Failure to observe this instruction may result in an accident or damage to the product.
- Do not allow any foreign object to enter the fan in this product. Failure to observe this instruction may result in an accident or damage to the product.


## 7.2.2 Changing direction of the pump suction port

With the factory setting, the pump suction port faces the left (when viewed from the pump side). If you change the direction of the pump suction port downward, turn the pump mounting angle counterclockwise by 90°, as shown in the figure below.


- 1) Remove two pump mounting bolts, and pull the pump shaft slightly from the motor in the axial direction.
- 2) Turn the pump unit counterclockwise by 90°, so that the suction port is located at the bottom.
- 3) Insert the pump, and fasten it with the mounting bolts. (Tightening torque: 30.0 N·m)

The pump shaft is a spline shaft, which can be removed from the motor by pulling it axially. The pump shaft need not be entirely pulled out.


Pump mounting bolt  
(M10 × 2)



- 1) Remove the mounting bolts, and pull the pump shaft slightly.



- 2) Turn the pump by 90°.



- 3) Insert the pump, and fasten it with the mounting bolts. (Tightening torque: 30.0 ± 3.0 N·m)




### CAUTION

- Please do not change the pump direction, if the pipe is attached or the external force is applied to the pump. There is a risk that pump may be damaged.
- Please ensure that the bolt is mounted to the pump. The pump may be damaged if these bolts loose.

### 7.3 Installation of the controller

- Install the controller vertically. Ensure at least 100 mm space above and under the controller. To access the controller during wiring, it is recommended that at least 30 mm space is provided on the left side of the controller.
- Be sure to install the controller in a control panel that provides IP54 enclosure rating.



### CAUTION

- Be sure not to harm yourself when installing the controller. It may cause an injury
- Mount the controller to an incombustible material, such as metal.
- Avoid installing the controller in a place where oil mist or airborne dust is present. Install the controller in a fully-enclosed panel (IP54) that does not allow entry of airborne substances.
- Install the controller in a place free from harmful gas or liquid, radioactive substances, or combustible substances.
- Install the controller in a place with little vibration.
- Install the controller in a place with little salt.
- Install the controller in a place where it is not exposed to direct sunlight.
- When a drill is used for installation work, take appropriate measures to prevent metal chips from entering inside of the controller. (For example, mount a protective cover to the controller.) After installation work, do not forget to remove the protective cover. If the controller is operated with the protective cover mounted, ventilation deteriorates, causing overheating of the controller, which may result in a fault of the controller.
- For an inductive load connected around the controller (electromagnetic contactor, electromagnetic relay, electromagnetic valve, solenoid, electromagnetic brake, etc.), be sure to provide a surge absorber.
- Particularly when several controllers are installed in a panel, the panel internal temperature will easily increase. Keep the controller's air intake temperature at 55°C or lower by using a cooling fan, etc.

## Chapter 8 Hydraulic Piping

Connect piping to all of the following ports:

Unit model	Discharge piping	Suction piping	Drain piping
SUT00D8021 SUT00D13021 SUT00D15021	P1	Suction port	T1

### Note

In order to maintain the cleanliness of the hydraulic fluid, please pay attention to the following matter.

- It is necessary to install filters in the suction side and the tank return line in this product. Please attach the suction filter of 150 mesh to the suction side, and attach the return filter of 10 $\mu$ m to the tank return line.
- Please keep the degree of hydraulic fluid contamination under NAS9 class.
- Please ensure the distance between the suction port and the tank bottom (10cm or more).
- Please ensure the distance between the suction port and the return port. Or put a (partition plate) baffle plate.
- Please install a filter (40 $\mu$ m or less) to the air breather.
- Please design the oil tank and make sure the waste cannot enter it.

## 8.1 Discharge pipe


Recommended specifications of the discharge pipes are listed below:

Unit model	Withstand pressure
SUT00D8021 SUT00D13021 SUT00D15021	27.5MPa

The hydraulic unit provides two P ports (P1 and P2).

Port No.	Name	Size
P1	Discharge port	Rc1
P2	Discharge port (Sealed with plug at shipment)	Rc1

Connect the piping as shown below.



Before shipment, the P1 port has been sealed with a resin plug with O-ring. The P2 port is sealed with a hexagon socket head plug.

Remove the resin plug with O-ring, and connect a hydraulic hose. Then, tighten the hose by winding seal tape.

 **CAUTION**


- For piping to this unit, use a hose.
- Select an appropriate hose length. If the connected hose is too long, it will shake during load fluctuations, causing interference with the main machine.
- During hose connection, make sure that the hose bend radius is larger than the allowable minimum bend radius given in the specifications, and that the hose will not twist.
- If excessive strain may be applied due to the hose weight, support the hose.
- For an unused port, attach a hexagon socket plug to block it. Otherwise, oil leak may occur.

## 8.2 Suction piping

Recommended specifications of the suction pipes are listed below:

Unit model	Withstand pressure	Size	Length
SUT00D8021	1.5 MPa	Rc 1-1/2	1.5 m or less
SUT00D13021		Rc 2	
SUT00D15021		Rc 2	

Connect a hose to the suction port via a suction flange. The suction flange should be prepared by the user. Order our optional parts, if required. Before shipment, the suction port has been sealed with a resin plug with O-ring. Remove the resin plug, and connect a hydraulic hose. Then, tighten the hose by winding seal tape. Please attach a suction filter of 150 mesh to the suction side.



### CAUTION

- For piping to this unit, use a hose.
- When connecting a hose, make sure that the hose bend radius is larger than that defined in the hose specifications.
- If the hose may develop excessive strain due to the hose weight, support the hose.
- Make sure that the suction pressure is in a range of  $-0.02$  to  $0.2$  MPa. If the suction pressure is lower than  $-0.02$  MPa, cavitation occurs, which may result in abnormal sound, flow rate reduction, and abnormal wear of the pump internal components. On the contrary, if the suction pressure exceeds  $0.2$  MPa, the pump seal parts may be damaged. Conform to the standard suction piping conditions given below.

SUT00D8021: The pipe diameter should be 1-1/2B or more, and the pipe length should be 1.5 m or less.

SUT00D13021: The pipe diameter should be 2B or more, and the pipe length should be 1.5 m or less.

SUT00D15021: The pipe diameter should be 2B or more, and the pipe length should be 1.5 m or less.

### 8.3 Drain piping


Recommended specifications of the suction piping are listed below:

Unit model	Withstand pressure
SUT00D8021	1.5 MPa
SUT00D13021	
SUT00D15021	

The hydraulic unit provides one drain port.

Port No.	Name	Size
T1	Drain port	Rc3/4
T2	Drain port (Sealed by plug)	Rc3/4

Connect the drain piping to the T1 port. The port size is Rc3/4. The recommended drain pipe diameter is Rc3/4. Connect the piping as shown below.



Before shipment, the T1 port has been sealed with a resin plug with O-ring. Remove the resin plug with O-ring, and connect a hydraulic hose. Then, tighten the hose by winding seal tape.


CAUTION

- For piping to this unit, use a hose.
- During hose connection, make sure that the hose bend radius is larger than the allowable minimum bend radius given in the specifications, and that the hose will not twist.
- If the hose may develop excessive strain due to the hose weight, support the hose.

## Chapter 9 Electric Wiring

- This hydraulic unit needs electric wiring of the main power supply, motor cable, motor cooling fan power supply, motor thermistor, encoder, pressure sensor, DC reactor, regenerative braking register and I/O signals, as required.  
For recommended cables and specifications, refer to detailed description on each connection.  
The controller does not include a set of sensor connectors. The harnesses are optionally available. For details, refer to “9.2.3” and “9.2.4 Encoder harness”.
- Connect the motor, motor cooling fan power supply and motor thermistor cables through the specified wiring holes.
- To protect the electric circuits against short-circuit and overcurrent, and to prevent an electric shock, provide a no-fuse breaker conforming to the EU standard EN60947-2 for the main power supply of the hydraulic unit.  
For details, refer to “9.1.1 Breaker”.
- As the power supply connection device, use a switch whose contact pitch is 3 mm or longer (on three poles) when the switch is OFF.

### WARNING

- Be sure to connect the ground terminal according to laws and ordinances of the country where this product is used. Connect the ground terminal directly without using a circuit breaker.
- Be sure to install the hydraulic unit first, before connecting the ground terminal.
- Before wiring work, be sure to turn OFF the main power supply breaker, and wait for at least 5 minutes.
- Connect the cable with the terminals so that they are not short-circuited and do not cause a ground fault. Otherwise, you may get an electric shock, or a fire may occur.

### CAUTION

- Do not connect the motor cable and the power supply cable to the I/O signal terminals. Otherwise, the controller will be damaged.
- Do not apply a power supply voltage higher than the hydraulic unit power supply rating. Otherwise, the controller will be damaged.
- Do not use a thermal relay, because the hydraulic unit incorporates an overcurrent protective function and does not need a thermal relay for overcurrent protection. If a thermal relay is used, the unit may malfunction due to inverter switching operation.
- To protect this product, provide a surge protector in the pre-stage of the controller power supply.
- To start and stop the hydraulic unit, use the start and stop signals of this product, without using an electromagnetic contactor. Otherwise, the power supply circuit devices will be damaged, causing damage to the controller.
- Be sure to connect the neutral point of the power supply to a ground line. If the insulation distance is too short, it may cause a failure of the controller.
- Do not share the controller's ground cable with a welding machine or power equipment. Otherwise, the power supply balance will deteriorate, causing a fault of the controller.
- Make the ground cable length short. If the controller is placed at a long distance from the ground point, the electric potential on the controller's ground terminal becomes unstable, because of a leak current flowing through the controller.
- When several controllers are used, make sure that the ground cable is not looped.
- Make sure that the motor cable, DCL cable and regenerative resistor cable do not touch the controller housing.
- After completion of wiring, be sure to check the wiring for the following points before turning ON the power supply.
  - Check for incorrect wiring.
  - Check for a waste wire or residual screw.
  - Check for loose connection of a screw.
  - Make sure that an unsheathed wire on a terminal does not touch other terminals.



## 9.1 Selection of Peripheral Equipment

### 9.1.1 Breaker

To prevent an accident with the power supply, be sure to use a no-fuse breaker conforming to the EU standard EN60947-2 for the power supply connection line.

Since the controller's output is switched at a high speed, the controller generates a high-frequency leak current. Therefore, for the controller's primary circuit, use an earth leakage breaker with high-frequency current countermeasures applicable to inverter equipment. Provide an earth leakage breaker with rated current sensitivity of 30 mA or more for one controller unit.

Unit model	Capacity of breaker
SUT00D8021-30-B-N0323	50A
SUT00D8021-21YB-N0324	30A
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	75A
SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	40A


## 9.2 Optional Electrical Equipment

### 9.2.1 DC reactor


To improve a power factor, use a DC reactor. Connect a DC reactor between the P1 and P2 terminals on the main power supply terminal block. For the wiring procedure, refer to "9.1.1.1 Connecting the DC reactor".

The type of the DC reactor is as follows:


Unit model	Type of option	Manufacturer
SUT00D8021-30-B-N0323	PM-SDL06	Daikin Industries, Ltd.
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	PM-SDL03	
SUT00D8021-21YB-N0324 SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	PM-SDL04	



PM-SDL06



PM-SDL03



PM-SDL04

### 9.2.2 Regenerative braking resistor


When the motor is running in the following conditions, the motor serves as a generator. For the wiring procedure, refer to “9.11.2 Connecting the regenerative braking resistor”.

The regenerative braking resistor consumes power generated by the motor in this status.

- Deceleration time in motor acceleration/deceleration step
- When the motor is under load
- When the motor rotates in the reverse direction under load

As an optional accessory, DAIKIN supplies the following regenerative braking resistor:

Type	Resistance	Manufacturer	Capacity	Lead length
PM-RB02	30Ω	Daikin Industries, Ltd.	500W	500mm
PM-RB04	10Ω			
PM-RB06	68Ω			



To use the above regenerative braking resistor, connect the specified number of resistors in parallel.

Unit Model	Option Type	Number	Connection
SUT00D8021-30-B-N0323	PM-RB02	3	Parallel
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365		6	
SUT00D8021-21YB-N0324	PM-RB06	2	
SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358		4	

### 9.2.3 Pressure sensor harness

For wiring of the pressure sensor, the following pressure sensor harness is optionally available. For the wiring procedure, refer to “9.10 Connecting the Pressure Sensor Harness”.

Unit Model	Option Type	Manufacturer
SUT00D8021-30-B-N0323	PM-SPH05-003	Daikin Industries, Ltd.
SUT00D8021-21YB-N0324	PM-SPH05-001	
SUT00D13021-10-B-N0321	PM-SPH05-003	
SUT00D13021-10YB-N0322	PM-SPH05-002	
SUT00D15021-10-B-N0365	PM-SPH05-003	
SUT00D15021-10YB-N0358	PM-SPH05-002	



Pressure sensor harness

### 9.2.4 Encoder harness

For wiring of the encoder, the following encoder harness is optionally available. For the wiring procedure, refer to “9.9 Connecting the Encoder”.

Unit Model	Option Type	Length	Manufacturer
SUT00D8021-30-B-N0323 SUT00D8021-21YB-N0324 SUT00D13021-10-B-N0321 SUT00D13021-10YB-N0322 SUT00D15021-10-B-N0365 SUT00D15021-10YB-N0358	PM-SEH05-P22-A09R	5m	Daikin Industries, Ltd.




Encoder harness  
PM-SEH05-P22-A09R

### 9.2.5 Ferrite core

If there is problem about noise emission from this hydraulic unit, wind a ferrite core on the power supply line to reduce noise interference.

The recommended ferrite cores are as follows. Please refer to "Chapter 15 Wiring diagram" for wiring method.

Unit Model	Option Type	Manufacturer Type	Manufacturer
SUT00D8021-30-B-N0323 SUT00D8021-21YB-N0324	PM-FC01	RFC-H13	Kitagawa Industries Co., Ltd.
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	PM-FC04 PM-FC05	RFC-20 RFC-10	
SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	PM-FC04	RFC-20	




### 9.2.6 Ring core

If there is problem about noise emission from this hydraulic unit, wind a ring core on the power supply line to reduce noise interference.

The recommended ring cores are as follows. Please refer to "Chapter 15 Wiring diagram" for wiring method.




Unit Model	Option Type	Manufacturer Type	Manufacturer
SUT00D8021-30-B-N0323 SUT00D8021-21YB-N0324	PM-SRC01	R47/27/15A MA055	JFE Steel Corporation
SUT00D13021-10-B-N0321 SUT00D13021-10YB-N0322	PM-SRC01	R47/27/15A MA055	JFE Steel Corporation
SUT00D15021-10-B-N0365 SUT00D15021-10YB-N0358	PM-SRC02	TRM-47-27-15E-WE	Kitagawa Industries Co., Ltd.




### 9.2.7 Noise filter

To prevent malfunction due to noise from the power supply line, or to prevent influence of noise from this hydraulic unit on external equipment, please use a noise filter. Followings are the recommended brands of noise filters for category C2/C3 in accordance with IEC68100-3. Select suitable ones according to your noise environment. Please refer to "Chapter 15 Wiring diagram" for wiring method.

Unit Model	Category	Option Type	Manufacturer Type	Manufacturer
SUT00D8021-30-B-N0323	C2	PM-SNF01	—	Daikin Industries, Ltd.
SUT00D8021-21YB-N0324	C2	PM-SNF03	3SUP-HL30-ER-6B	Okaya Electric Industries Co., Ltd
	C3	PM-SNF06	FN3025HP-30-71	Shaffner EMC Co., Ltd.
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	C2	PM-SNF02	NF3060A-VZ	Soshin Electric Co., Ltd.
		PM-SNF04	FN3011-75-62	Shaffner EMC Co., Ltd.
SUT00D13021-10YB-N0322	C2	PM-SNF03	3SUP-HL30-ER-6B	Okaya Electric Industries Co., Ltd
SUT00D15021-10YB-N0358	C3	PM-SNF06	FN3025HP-30-71	Shaffner EMC Co., Ltd.






### 9.2.8 Optional accessory set

Unit Model	Option Type	Description	
		Name	Name
SUT00D8021-30-B-N0323	PM-SOP16	DC reactor	PM-SDL06
		Regenerative resistor	PM-RB02 (3 pieces)
		Encoder harness	PM-SEH05-P22-A09R
		Pressure sensor harness	PM-SPH05-003
		Ferrite core	PM-FC01
		Ring core	PM-SRC01
	PM-SOP17	DC reactor	PM-SDL06
		Regenerative resistor	PM-RB02 (3 pieces)
		Encoder harness	PM-SEH05-P22-A09R
		Pressure sensor harness	PM-SPH05-003
		Ferrite core	PM-FC01
		Ring core	PM-SRC01
SUT00D8021-21YB-N0324	PM-SOP04	DC reactor	PM-SDL04
		Regenerative resistor	PM-RB06 (2 pieces)
		Encoder harness	PM-SEH05-P22-A09R
		Pressure sensor harness	PM-SPH05-001
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	PM-SOP10	DC reactor	PM-SDL03
		Regenerative resistor	PM-RB02 (6 pieces)
		Encoder harness	PM-SEH05-P22-A09R
		Pressure sensor harness	PM-SPH05-003
SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	PM-SOP08	DC reactor	PM-SDL04
		Regenerative resistor	PM-RB06 (4 pieces)
		Encoder harness	PM-SEH05-P22-A09R
		Pressure sensor harness	PM-SPH05-002

To ensure conformity to the EMC (Electro Magnetic Compatibility) standard, additional components (noise filter, ring core, ferrite core, etc.) are required. Prepare these components separately, as required. For details, refer to “Chapter 15 Wiring diagram”.


### 9.3 Electrical Connection Diagram (Overall)

●SUT00D8021-30-B-N0323 / SUT00D13021-10-B-N0321 / SUT00D15021-10-B-N0365



- Located on the "main power supply terminal block" of the controller.
- Located on the "user I/O terminal block" of the controller.
- Located in the motor terminal box.

● SUT00D8021-21YB-N0324 / SUT00D13021-10YB-N0322 / SUT00D15021-10YB-N0358  
 3φ AC380—440 V 50/60 Hz




- Located on the "main power supply terminal block" of the controller.
- Located on the "user I/O terminal block" of the controller.
- Located in the motor terminal box.

## 9.4 Terminal Connections

### 9.4.1 Crimp terminal

Prepare crimp terminals as shown below.

- Use crimp terminals. For specification of each terminal, refer to detailed description on each connection.
- Crimp each terminal with the cable conductors protruding from the terminal by approx. 1 mm.



CAUTION

- Do not conduct crimp work with live wires or around live wires. Otherwise, you may get an electric shock.
- Use an appropriate crimp terminal conforming to the cable size. Otherwise, you may get an electric shock, or a fire may occur.
- To crimp a terminal, use an appropriate tool for the crimp terminal. Otherwise, you may get an electric shock, or a fire may occur.


### 9.4.2 Recommended wire

VCT wire, CE wire are recommended

	Name	JIS Standard
VCT wire	600V Vinyl-insulated cable (600 V Grade Polyvinyl Chloride Insulated and Sheathed Portable Power Cables)	JIS C3312
CE wire	CE standard compliant cable	-

### 9.4.3 Connections to the controller

Connections to the controller are shown below. For details, refer to description on each connection. Components to be connected to each terminal are shown in the table below.




Terminal block	Terminal code	Cable to connect
Main power supply terminal block	L1/L2/L3	Main power supply
	P1/P2	DC reactor
	B1/B2	Regenerative braking resistor
	U/V/W	Motor output
User I/O terminal block	See the terminal assignment of the I/O terminal block.	Encoder
		Motor thermistor
		Pressure sensor
		I/O signals

## ⚠ CAUTION

- Do not use the terminals indicated as “Unused”. Using these terminals for any other purpose results in damage to the controller.

Terminal assignment of the I/O terminal block is as follows:


I/O terminal block	Terminal No.	Terminal code	Name	Terminal No.	Terminal code	Name
	25	FG	Frame ground	1	FG	Frame ground
	26	+5V	+5 V power supply	2	GND	Ground
	27	Z+	Encoder Z phase +	3	Z-	Encoder Z phase -
	28	B+	Encoder B phase +	4	B-	Encoder B phase -
	29	A+	Encoder A phase +	5	A-	Encoder A phase -
	30	THM+	Thermistor +	6	THM-	Thermistor -
	31	AO2 (QO)	Analog output 2	7	AGND	Analog ground
	32	AO1 (PO)	Analog output 1	8	AGND	Analog ground
	33	AI2 (QI)	Analog input 2	9	AGND	Analog ground
	34	AI1 (PI)	Analog input 1	10	AGND	Analog ground
	35	P_S	Pressure sensor signal	11	AGND	Analog ground
	36	ALM_C	Contact output common	12	A5V	Pressure sensor power supply
	37	ALM_A	Contact output a	13	ALM_B	Contact output b
	38	DO7	(Unused)	14	DOCOM	Digital output common
	39	DO5	(Unused)	15	DO6	(Unused)
	40	DO3	(Unused)	16	DO4	Digital output 4
	41	DO1	Digital output 1	17	DO2	(Unused)
	42	DI7	(Unused)	18	DI8	(Unused)
	43	DI5	(Unused)	19	DI6	(Unused)
	44	DI3	(Unused)	20	DI4	(Unused)
	45	DI1	Digital input 1	21	DI2	(Unused)
	46	DGND	(Unused)	22	DICOM	Digital input common
	47	TxD	(Unused)	23	RxD	(Unused)
	48	FG	Frame ground	24	FG	Frame ground



- Do not use the terminals indicated as “Unused”. Using these terminals for any other purpose results in damage to the controller.


### 9.4.4 Connections to the motor

Connections to the motor terminals, thermistor terminals, and motor cooling fan terminals are provided in the terminal box. You can remove the terminal box cover by loosening the screws (at four places).



- Screw size: M6
- Recommended tightening torque: 2.6 [N•m]


Connections to the motor are shown below. For details, refer to each connecting procedure.



Components to be connected with each terminal are listed in the table below.

Terminal	Cable to connect
Motor connection terminal	Motor cable
Motor cooling fan power supply connection terminal	Motor cooling fan power supply cable
Thermistor connection terminal	Thermistor cable

**9.5 Connecting the Power Supply**



1) Prepare the power supply cable and crimp terminals.

● SUT00D8021-30-B-N0323

When using 60°C cable	Power supply cable	Wire cross-section area: 8 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 8 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-6
When using 70°C cable	Power supply cable	Wire cross-section area: 6 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 6 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: RBP5.5-6

● SUT00D8021-21YB-N0324

When using 60°C cable	Power supply cable	Wire cross-section area: 8 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 8 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-6
When using 70°C cable	Power supply cable	Wire cross-section area: 6 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 6 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: RBP5.5-6

● SUT00D13021-10-B-N0321

● SUT00D15021-10-B-N0365

When using 60°C cable	Power supply cable	Wire cross-section area: 14 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 14 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R14-6
When using 70°C cable	Power supply cable	Wire cross-section area: 10 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 10 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: R8-6

- SUT00D13021-10YB-N0322
- SUT00D15021-10YB-N0358

When using 60°C cable	Power supply cable	Wire cross-section area: 14 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 14 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M8 screw Recommended: R14-6
When using 70°C cable	Power supply cable	Wire cross-section area: 10 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 10 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: RBP5.5-6

- 2) Connect the ground cable to the power supply ground terminal. Recommended tightening torque is 3.5 [N·m].
- 3) Connect the power supply cable to the terminal block. Do not use the power supply ground terminal screw. The power supply ground terminal screw is identified by green color.  
The phase order of the input power supply is not related to that of the terminal block. The input power supply can be also connected to L1, L2 and L3 terminals.

To prevent malfunction due to noise from a power line, and to suppress influence of noise from the controller on external equipment, use a noise filter.



### **WARNING**

- Use an AC power supply conforming to the power supply specifications of the hydraulic unit.
- Use a power supply cable conforming to the power supply specifications.
- Do not connect a power supply cable to the ground terminal.
- Be sure to connect the ground terminal according to laws and ordinances of the country where this product is used.
- When you unsheath the power supply cable, be careful not to damage the conductors.
- Make sure that the cable conductors are not protruding from the terminal block.
- Connect the cable with the terminals so that they are not short-circuited and do not cause a ground fault. Otherwise, you may get an electric shock, or a fire may occur.
- Do not confuse the power supply ground terminal screw with the main power supply connection terminal screw. If the main power supply connection terminal is tightened with the power supply ground terminal screw, the power supply cable may not be securely fastened. This causes the terminal block to heat up, resulting in a fire. To prevent confused use of the terminal screws, the power supply ground terminal screw is identified by green color.


### **CAUTION**

- To connect the end of each cable, use a crimp terminal.
- Place the noise filter ground cable away from output cables as far as possible.
- Separate the noise filter input and output lines. Use caution when you tie the cables or place the cables in the same conduit.
- To start and stop the hydraulic unit, use the start and stop signals of the unit, without using an electromagnetic contactor. To turn ON/OFF the electromagnetic contactor, make sure that the hydraulic unit has completed stopped. Otherwise, the power supply circuit devices may be damaged.

9.6 Connecting the Motor Cable



9.6.1 Connections to the controller



◆ Recommended tightening torque: 3.5 [N•m]

Please prepare the motor cable and crimp terminals. The motor cable length should be 5 m or less.

●SUT00D8021-30-B-N0323

When using 60°C cable	Motor cable	Wire cross-section area: 5.5 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 5.5 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal (controller)	Crimp terminal with insulation sheath (R type), Round terminal for M6 screw Recommended: RBP 5.5-6
	Crimp terminal (motor)	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R5.5-6
When using 70°C cable	Power supply cable	Wire cross-section area: 4 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 4 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal (controller)	Crimp terminal with insulation sheath (R type), Round terminal for M6 screw Recommended: RBP 5.5-6
	Crimp terminal (motor)	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: RBP 5.5-6

●SUT00D13021-10-B-N0321

●SUT00D15021-10-B-N0365

When using 60°C cable	Power supply cable	Wire cross-section area: 14 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 14 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R14-6
When using 70°C cable	Power supply cable	Wire cross-section area: 10 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 10 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: R8-6

●SUT00D8021-21YB-N0324

When using 60°C cable	Power supply cable	Wire cross-section area: 8 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 8 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-6
When using 70°C cable	Power supply cable	Wire cross-section area: 6 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 6 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Crimp terminal with insulation sheath, Round terminal for M6 screw Recommended: RBP5.5-6

●SUT00D13021-10YB-N0322

●SUT00D15021-10YB-N0358

When using 60°C cable	Power supply cable	Wire cross-section area: 14 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 14 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R14-6
When using 70°C cable	Power supply cable	Wire cross-section area: 10 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 10 mm <sup>2</sup> × 4 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Bare crimp terminal, Round terminal for M6 screw Recommended: R8-6

- 1) Connect the ground cable to the motor ground terminal. The ground cable size should be equal to, or larger than that of the motor cable.
- 2) Connect the motor cable to the connection terminals with correct phases on the terminal block.  
Do not use the motor ground terminal screw. The motor ground terminal screw is identified by green color.

 **WARNING**


- Do not confuse the motor ground terminal screw with the motor connection terminal screw. If the motor connection terminal is tightened with the motor ground terminal screw, the motor cable may not be securely fastened. This causes the terminal block to heat up, resulting in a fire. To prevent confused use of the terminal screws, the motor ground terminal screw is identified by green color.

 **CAUTION**

- Do not turn ON/OFF the contactor during operation, with the contactor connected between the motor cables. If the electromagnetic contactor is turned ON during operation, a large current flows through the circuit, causing damage to the controller.
- Do not connect a leading-phase capacitor or noise filter between the controller and the motor. Otherwise, the controller's higher harmonics cause overheating or damage of the capacitor or noise filter. Also, this may result in damage to the controller.
- If the motor cables are placed together in a grounded metal conduit, radiant noise can be reduced. Furthermore, if the signal cables are placed at 30 cm or longer distance from a power cable, noise interference can be reduced.

## 9.6.2 Connections to the motor

Connect the cable that has been prepared in the controller connection step to the motor.



Terminal name	Terminal code
Motor cable U phase	U (Red)
Motor cable V phase	V (White)
Motor cable W phase	W (Black)
Ground	

◆ Recommended tightening torque

Motor connection terminal (M6)	4.3 [N•m]
Motor ground terminal (M6)	2.6 [N•m]

◆ Wiring port size

SUT00D8021-30-B-N0323	φ28
SUT00D8021-21YB-N0324	
SUT00D13021-10-B-N0321	φ34
SUT00D15021-10-B-N0365	
SUT00D13021-10YB-N0322	
SUT00D15021-10YB-N0358	

- 1) To protect the cable and prevent a foreign object from entering the terminal box during wiring, use a grommet suitable for the wiring hole. The cable clamp for wiring is not included in the product. It should be prepared by the user.
- 2) Connect the ground cable to the motor ground terminal. The ground cable size should be equal to, or larger than that of the motor cable.
- 3) Connect the motor cable to the connection terminals with correct phases.

### WARNING

- Do not connect the power supply cable to the motor connection terminals. Incorrect wiring may result in a fire or other accident.
- After completion of the wiring, be sure to re-mount the cover to the motor terminal box. Otherwise, you may get an electric shock.


### CAUTION

- When connecting the motor cable, use caution not to connect the cable with incorrect phases. Incorrect wiring may result in unintended operation of the motor (reverse rotation etc.).
- Do not connect a contactor to the motor cable.

## 9.7 Connecting the Motor Cooling Fan

The motor cooling fan power supply specifications are as follows: The main machine should be equipped with the motor cooling fan power supply.

Power supply	200V : 1 φ 200V
	400V : 1 φ 230V



Terminal name	Indication
Motor cooling fan power supply connection terminal	AC FAN
	AC FAN
Motor cooling fan power supply ground terminal	⊕

\* The motor cooling fan power supply has no polarity.

◆ Recommended tightening torque

Motor cooling fan power supply connection terminal (M3.5)	0.8 [N•m]
Motor cooling fan power supply ground terminal (M4)	0.8 [N•m]

◆ Wiring port size: φ21

- 1) Prepare the power supply cable and crimp terminals. The length of the power supply cable should be 5 m or less.


Motor cooling fan power supply cable	When using 60°C cable	Wire cross-section area: 0.5 mm <sup>2</sup> or more, Rated voltage: 300 V Recommended: VCTF36 0.5 mm <sup>2</sup> × 3 wires, Kuramo Electric Co., Ltd.
	When using 70°C cable	Wire cross-section area: 0.5 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 0.5 mm <sup>2</sup> × 3 wires, Kuramo Electric Co., Ltd.
Crimp terminal	Crimp terminal with insulation sheath (R type), Round terminal for Power supply : M3.5 screw Recommended: RBP1.25-4 Ground terminal : M4 screw Recommended: RBP1.25-3.5	

- 2) To protect the cable and prevent a foreign object from entering the terminal box during wiring, use a cable clamp suitable for the wiring hole. The cable clamp used for wiring is not included in the product. It should be prepared by the user.
- 3) Connect the ground cable to the motor cooling fan power supply ground terminal. The ground cable size should be equal to, or larger than that of the motor cooling fan power supply cable.
- 4) The motor cooling fan power supply connection terminals have no polarity.

⚠ WARNING
• After completion of the wiring, be sure to re-mount the cover to the motor terminal box. Otherwise, you may get an electric shock.

⚠ CAUTION
• Be careful not to connect the motor cooling fan power supply cable to the thermistor terminals. Incorrect wiring causes damage to the thermistor, resulting in a fire or other accident.

## 9.8 Connecting the Motor Thermistor Harness



### 9.8.1 Connections to the controller

- 1) Prepare the motor thermistor harness and crimp terminals.

Motor thermistor harness	Wire cross-section area: 0.3 mm <sup>2</sup> or more, Rated voltage: 300 V Recommended: KVC-36 0.3 mm <sup>2</sup> × 2 wires, Kuramo Electric Co., Ltd.
Crimp terminal	Controller side Crimp terminal with insulation sheath (R type), Round terminal for M3 screw Recommended: RBP1.25-3
	Motor side Crimp terminal with insulation sheath (R type), Round terminal for M3.5 screw Recommended: RBP1.25-3.5

- 2) Verify specifications of the signal, and connect the signal cable between the [THM+] and [THM-] terminals on the I/O terminal block.

Recommended tightening torque is 0.6 [N•m].


If the motor is started with incorrect wiring of the motor thermistor harness, the motor may be damaged. Connect the motor thermistor harness to the specified terminals correctly.



- If the motor cooling fan power supply cable is incorrectly connected to the motor thermistor terminals, it causes damage to the motor.

### 9.8.2 Connections to the motor

Connect the motor thermistor harness to the motor.



Terminal name	Indication
Motor thermistor connection terminal	THM
	THM

\* The thermistor connection terminals have no polarity.


- ◆ Recommended tightening torque: 0.8 [N•m]
- ◆ Wiring port size: φ21

- 1) To protect the cable and prevent a foreign object from entering the terminal box during wiring, use a cable clamp suitable for the wiring hole.  
The cable clamp used for wiring is not included in the product. It should be prepared by the user.
- 2) Connect the motor thermistor harness to the thermistor connection terminals. Recommended tightening torque is 0.8 [N•m].  
The thermistor connection terminals have no polarity.

## ⚠ WARNING

- After completion of the wiring, be sure to re-mount the cover to the motor terminal box. Otherwise, you may get an electric shock.

9.9 Connecting the Encoder




- 1) Prepare the encoder harness, crimp terminals, connector and dedicated wiring tool.

Encoder harness	<p>Wire cross-section area: 0.3 mm<sup>2</sup> or more, Rated voltage: 150 V                  Recommended: KVC-36SB 0.3 mm<sup>2</sup> × 8 wires, Kuramo Electric Co., Ltd.</p> <p>The encoder harness is optionally available.</p> <table border="1" data-bbox="711 1314 1325 1442"> <thead> <tr> <th>Option model</th> <th>Cable length</th> </tr> </thead> <tbody> <tr> <td>PM-SEH05-P22-A09R</td> <td>5 m</td> </tr> </tbody> </table>	Option model	Cable length	PM-SEH05-P22-A09R	5 m																										
Option model	Cable length																														
PM-SEH05-P22-A09R	5 m																														
Crimp terminal on the controller side	<p>Crimp terminal with insulation sheath (R type), Round terminal for M3 screw                  Recommended: RBP1.25-3</p>																														
Connector on the motor side	<p>Manufacturer: Tyco Electronics AMP K. K.                  Housing: 172169-1                  Contact: 170366-1                  Dedicated tool: 91522-1</p> <table border="1" data-bbox="674 1739 1877 2220"> <thead> <tr> <th>Terminal No.</th> <th>Terminal code</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A+</td> <td>Encoder A phase +</td> </tr> <tr> <td>2</td> <td>A-</td> <td>Encoder A phase -</td> </tr> <tr> <td>3</td> <td>B+</td> <td>Encoder B phase +</td> </tr> <tr> <td>4</td> <td>B-</td> <td>Encoder B phase -</td> </tr> <tr> <td>5</td> <td>Z+</td> <td>Encoder Z phase +</td> </tr> <tr> <td>6</td> <td>Z-</td> <td>Encoder Z phase -</td> </tr> <tr> <td>7</td> <td>+5V</td> <td>+5 V power supply</td> </tr> <tr> <td>8</td> <td>GND</td> <td>Ground</td> </tr> <tr> <td>9</td> <td>FG</td> <td>Frame ground</td> </tr> </tbody> </table>	Terminal No.	Terminal code	Name	1	A+	Encoder A phase +	2	A-	Encoder A phase -	3	B+	Encoder B phase +	4	B-	Encoder B phase -	5	Z+	Encoder Z phase +	6	Z-	Encoder Z phase -	7	+5V	+5 V power supply	8	GND	Ground	9	FG	Frame ground
Terminal No.	Terminal code	Name																													
1	A+	Encoder A phase +																													
2	A-	Encoder A phase -																													
3	B+	Encoder B phase +																													
4	B-	Encoder B phase -																													
5	Z+	Encoder Z phase +																													
6	Z-	Encoder Z phase -																													
7	+5V	+5 V power supply																													
8	GND	Ground																													
9	FG	Frame ground																													


- 2) Verify specifications of each signal by referring to the connection diagram shown in “Chapter 15 Wiring diagram”, and connect the signal cable to the I/O terminal block. Recommended tightening torque is 0.6 [N•m].
- 3) Connect to the connector to the encoder connector.

 **CAUTION**

- Make sure that the encoder connections are correct. Incorrect wiring may result in unintended operation of the motor (reverse rotation etc.).
- Clamp the encoder harness on the motor cooling fan mounting base, in order to prevent excessive force from being applied to the encoder connector. If excessive force is applied to the harness, it may cause a harness wire break.



9.10 Connecting the Pressure Sensor Harness



The pressure sensor mounting position varies depending on the unit model. Refer to “4.1 Part Names of Each Unit”.

- 1) Prepare the pressure sensor harness, crimp terminals, connector and dedicated wiring tool.


Pressure sensor harness	Wire cross-section area: 0.5 mm <sup>2</sup> or more, Rated voltage: 300 V Recommended: KVC-36SB 0.5 mm <sup>2</sup> × 3 wires, Kuramo Electric Co., Ltd.  The pressure sensor harness is optionally available.		
	Unit model	Option model	Cable length
	SUT00D8021-30-B-N0323	PM-SPH05-003	5m
	SUT00D8021-21YB-N0324	PM-SPH05-001	5m
	SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	PM-SPH05-003	5m
	SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	PM-SPH05-002	5m
Crimp terminal on the controller side	Crimp terminal with insulation sheath (R type), Round terminal for M3 screw Recommended: RBP1.25-3		
Connector on the motor side	Manufacturer: Tyco Electronics AMP K. K. Housing: 174357-2 Contact: 171630-1 Rubber plug; 172746-1 Double lock plate: 1-174358-1 Dedicated tool: 91583-1		
		Terminal No.	Terminal code
	1	AGND	Analog ground
	2	P_S	Pressure sensor signal
	3	A5V	Pressure sensor power supply

Ferrite core	Unit model	Ferrite core, Ring core
	SUT00D8021-21YB-N0324	Manufacturer: Kitagawa Industries Co., Ltd. Ferrite core: TRM-47-27-15E-WE * Attach the ferrite core to the pressure sensor harness by three turns, at 100 mm distance from the terminal on the controller side, and fasten it.
	SUT00D8021-30-B-N0323 SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	Manufacturer: JFE Steel Corporation Ring core: R47/27/15A MA055 (Daikin: PM-SRC01) *Attach the ring core to the pressure sensor harness by three turns, at 100 mm distance from the terminal on the controller side, and fasten it.
	SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	Manufacturer: JFE Steel Corporation Ring core: R47/27/15A MA055(Daikin: PM-SRC01) *Attach the ring core to the pressure sensor harness by three turns, at 100 mm distance from the terminal on the controller side, and fasten it.

- 2) By referring to specifications of each signal with the connection diagram shown in “Chapter 15 Wiring diagram”, and connect the signal cable to the I/O terminal block. Recommended tightening torque is 0.6 [N•m].
- 3) Connect the connector to the pressure sensor.

 <b>CAUTION</b>
Clamp the pressure sensor harness at a part near the sensor, to prevent excessive force from being applied to the connector due to influence of motor pump vibration. If excessive force is applied to the harness, it may cause a harness wire break.

## 9.11 Connecting Peripheral Equipment



### 9.11.1 Connecting the DC reactor

- 1) Prepare the following DC reactor.

Unit model	Type of option	Manufacturer
SUT00D8021-30-B-N0323	PM-SDL06	Daikin Industries, Ltd.
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	PM-SDL03	
SUT00D8021-21YB-N0324 SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	PM-SDL04	

- 2) Prepare the DC reactor connection cable and crimp terminals

- SUT00D8021-30-B-N0323

Please use the wires and crimp terminals attached in the DC reactor.

- SUT00D13021-10-B-N0321 / SUT00D15021-10-B-N0365

When using VCT cable	DC reactor connection cable	Wire cross-section area: 14mm <sup>2</sup> or more Recommended: VCT360 14mm <sup>2</sup> × 2 wires Kuramo Electric Co., Ltd
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R14-6
When using CE cable	DC reactor connection cable	Wire cross-section area: 10mm <sup>2</sup> or more Recommended: CE362 10mm <sup>2</sup> × 2 wires Kuramo Electric Co., Ltd
	Crimp terminal	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-6

- SUT00D8021-21YB-N0324

When using 60°C cable	DC reactor connection cable		Wire cross-section area: 8 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 8 mm <sup>2</sup> × 2 wires, Kuramo Electric Co., Ltd
	Crimp terminal	Controller side	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-6
		DC reactor side	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-5
When using 70°C cable	DC reactor connection cable		Wire cross-section area: 6 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 6 mm <sup>2</sup> × 2 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Controller side	Crimp terminal with insulation sheath (R type), Round terminal for M6 screw Recommended: RBP5.5-6
		DC reactor side	Crimp terminal with insulation sheath (R type), Round terminal for M5 screw Recommended: RBP5.5-5

● SUT00D13021-10YB-N0322 / SUT00D15021-10YB-N0358

When using 60°C cable	DC reactor connection cable		Wire cross-section area: 14 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: VCT360 14 mm <sup>2</sup> × 2 wires, Kuramo Electric Co., Ltd
	Crimp terminal	Controller side	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R14-6
		DC reactor side	Bare crimp terminal (R type), Round terminal for M6 screw Recommended: R8-5
When using 70°C cable	DC reactor connection cable		Wire cross-section area: 6 mm <sup>2</sup> or more, Rated voltage: 600 V Recommended: CE362 6 mm <sup>2</sup> × 2 wires, Kuramo Electric Co., Ltd.
	Crimp terminal	Controller side	Crimp terminal with insulation sheath (R type), Round terminal for M6 screw Recommended: RBP5.5-6
		DC reactor side	Crimp terminal with insulation sheath (R type), Round terminal for M6 screw Recommended: RBP5.5-5

- 3) Connect the DC reactor connection cable between the [P1] and [P2] terminals on the main power supply terminal block. Recommended tightening torque is 3.5 [N•m].
- 4) Connect the DC reactor connection cable to the DC reactor. The DC reactor connection cable should be as short as possible. Place the DC reactor connection cable away from a signal line as far as possible. Do not tie the DC reactor connection cable together with signal cables.

⚠ CAUTION
<ul style="list-style-type: none"> <li>For connection of DCL, use thorough caution not to short-circuit the wiring. Short-circuited wiring causes damage to the controller.</li> <li>Do not touch DCL, because it becomes hot.</li> </ul>

### 9.11.2 Connecting the regenerative braking resistor

- 1) Prepare the regenerative braking resistor conforming to the following specifications: DAIKIN supplies the following regenerative braking resistors as optional accessories. For details, refer to “9.2.2 Regenerative braking resistor”.

Unit model	Capacity	Combination resistance
SUT00D8021-30-B-N0323	1.5 kW or more	10 Ω
SUT00D8021-21YB-N0324	1 kW or more	34 Ω
SUT00D13021-10-B-N0321 SUT00D15021-10-B-N0365	3 kW or more	5 Ω
SUT00D13021-10YB-N0322 SUT00D15021-10YB-N0358	2 kW or more	17 Ω

- 2) Prepare crimp terminals. To extend the cable length, use a cable with 2 mm<sup>2</sup> wire cross-section area or larger size.

Crimp terminal	<ul style="list-style-type: none"> <li>• Controller side</li> </ul> Crimp terminal with insulation sheath (R type), Round terminal for M6 screw Recommended: RBP2-6
	<ul style="list-style-type: none"> <li>• Regenerative resistor side</li> </ul> Crimp terminal with insulation sheath (R type), Round terminal for M4 screw Recommended: RBP2-4

- 3) Connect the regenerative resistor connection cable between the [B1] and [B2] terminals on the main power supply terminal block. Recommended tightening torque is 3.5 [N•m]



### CAUTION

- When connecting the regenerative resistor, use thorough caution so that the regenerative resistor is not short-circuited. Short-circuiting the regenerative resistor results in damage to the internal circuit.
- When a regenerative resistor is externally mounted, it may become hot (200°C or higher temperature). For installation of the regenerative resistor, use a heat-resistant cable, and cover the resistor to prevent burns.
- To ensure safety, provide a thermal switch. Connect the switch so as to activate a protective circuit.
- If the combination resistance is less than 34 Ω, the internal circuit may be damaged. Be sure to connect a resistor that provides resistance of 34 Ω.

**9.12 Connecting the I/O Signal Cables**

1) Prepare the I/O signal cables and crimp terminals.

I/O signal cable	Wire cross-section area: 0.3 mm <sup>2</sup> or more, Rated voltage: 150 V Recommended: KVC-36SB 0.3 mm <sup>2</sup> , Kuramo Electric Co., Ltd.
Crimp terminal	Crimp terminal with insulation sheath (R type), Round terminal for M3 screw Recommended: RBP1.25-3


2) Verify specifications of each signal, and connect the signal cable to the I/O terminal block.  
Recommended tightening torque is 0.6 [N•m].

 <b>WARNING</b>
<ul style="list-style-type: none"> <li>• When you unsheathe each cable, be careful not to damage the conductors.</li> <li>• Make sure that the cable conductors are not protruding from the terminal block.</li> </ul>

 <b>CAUTION</b>
<ul style="list-style-type: none"> <li>• Do not connect the I/O signal cables to the power supply terminal block.</li> <li>• Verify specifications of each signal cable before connecting the cable.</li> <li>• Terminate the shielded cable securely, and connect the cable to the shield cable ground terminal.</li> <li>• If noise cannot be eliminated even when the signal cables are connected to the shielded cable ground terminal, ground your equipment singly. (Disconnect the ground terminal of the hydraulic unit.)</li> </ul>

### 9.12.1 Specifications of I/O signals

Specifications of the I/O signal terminals used for external interface are as follows:



#### ◆ Analog input

The hydraulic unit inputs pressure command and flow rate command analog voltages from the main machine.

Terminal No.	Terminal name	Signal name	Rated capacity	Function
33	AI2 (QI)	Analog input 2	0 to 10 V DC Input resistance: 20 kΩ ± 2%	Inputs a flow rate command. The relationship between the input voltage and target flow rate can be adjusted with the parameter. For details, refer to “11.2.1 Input command voltage scaling value”.
9	AGND	Analog ground		Ground for AI2 circuit
34	AI1 (PI)	Analog input 1		Inputs a pressure command. The relationship between the input voltage and target pressure can be adjusted with the parameter. For details, refer to “11.2.1 Input command voltage scaling value”.
10	AGND	Analog ground		Ground for AI1 circuit

#### ◆ Analog output

Current pressure and flow rate can be monitored with analog voltages.

Terminal No.	Terminal name	Signal name	Rated capacity	Function
31	AO2 (QO)	Analog output 2	-10 to 10 V DC	Outputs the current flow rate value.
7	AGND	Analog ground		Ground for AO2 circuit
32	AO1 (PO)	Analog output 1	0 to 10 V DC	Outputs the current pressure value.
8	AGND	Analog ground		Ground for AO1 circuit

◆ Digital input

Terminal No.	Terminal name	Signal name	Rated capacity	Function
18	DI8	(Unused)	DC24V 5mA	-
42	DI7	(Unused)		-
19	DI6	(Unused)		-
43	DI5	Pump capacity selection signal		You can choose the PQ characteristics in accordance with the pump state. Please refer to: "11.2.7 [DI_L H47]" for more information.
20	DI4	(Unused)		-
44	DI3	(Unused)		-
21	DI2	(Unused)		-
45	DI1	Digital input 1		Starts or stops the motor. With the "P00" parameter, you can specify the start input signal logic. For details, refer to "11.2.4 [P00:DI_A]".
22	DICOM	Digital input common		Positive common / Negative common

⚠ CAUTION
<ul style="list-style-type: none"> <li>For an external power supply, prepare a 24 VDC ± 1 V power supply with 0.5 A or more current capacity.</li> <li>This controller cannot feed power to external equipment.</li> <li>A current of 5 mA (typical) flows through each input circuit. To build a circuit with a contact, use caution about the minimum current capacity of the contact.</li> </ul>

◆ Digital output

Terminal No.	Terminal name	Signal name	Rated capacity	Function
14	DOCOM	Digital output common	DC24V 30mA or less	Negative common
38	DO7	(Unused)		-
15	DO6	(Unused)		-
39	DO5	(Unused)		-
16	DO4	Digital output 4		When a warning condition occurs, the signal turns ON. For details of warning output, refer to "14.1.2 Description of warnings".
40	DO3	(Unused)		-
17	DO2	(Unused)		-
41	DO1	Digital output 1		When the hydraulic unit is ready for operation, the signal turns ON.


**CAUTION**

- Prepare an external power supply with 24 VDC  $\pm$  1 V and 0.5 A ratings.
- This controller cannot feed power to external equipment.
- The maximum output current of the output circuit is 40 mA (resistance load) per circuit.  
If the circuit drives a load exceeding the allowable current, the circuit may be damaged. Be sure to connect a load less than the maximum output current.
- To drive an inductive load, provide surge-suppressing measures.

## ◆ Contact output

Terminal No.	Terminal name	Signal name	Rated capacity	Function
36	ALM_C	Contact output common	24 V DC, 0.5 A max. Minimum load current: 10 mA	Activates an alarm output under negative logic. [Normal status] ALM_A = ON, ALM_B = OFF [Error] ALM_A = OFF, ALM_B = ON For details of alarms, refer to “14.1.1 Description of alarms”.
13	ALM_B	Contact output b		
37	ALM_A	Contact output a		



**CAUTION**

- The contact switching capacity is 30 VDC/0.5 A (resistance load). If the circuit drives a load exceeding the allowable current, the contact may be damaged. Use caution about the current capacity.
- For contact output, the minimum applicable load is 10 mA DC/10  $\mu$ A. However, this value is the standard value of the lower limit that enables contact switching under minute load. This value varies depending on switching frequency and environmental conditions of the contact. It is recommended that you verify the minimum allowable current with actual load.
- To drive an inductive load, provide surge-suppressing measures.



## Chapter 10 Panel Operations

### 10.1 Parts Names and Principal Functions of the Operation Panel



The controller provides a 3-digit display and four key switches, as shown on the left.

In the normal mode, the display indicates a current pressure value (MPa).

Name		Principal function	
LED display		Displays a pressure/flow rate monitor value, or a set value of each function. In the normal mode, a current pressure value is displayed.	
MODE key			Operate this key to select the normal mode or the monitor mode.
Setting keys	DOWN key		Operate these keys to select a monitor item and parameter No., and to change a parameter setting. Pressing the UP key increments a set value. Pressing the DOWN key decrements a set value.
	UP key		
ENT key			Operate this key to register a parameter No., parameter setting or other selected condition.

### 10.2 Functions of the Operation Panel

#### 10.2.1 Outline of functions


The operation panel provides the following functions:

##### ◆ Functions of the operation panel

Mode	Description
Normal mode	A current pressure value is displayed.
Monitor mode	You can confirm a pressure/flow rate command voltage and current value with the LED display.
Setting mode	You can specify various parameters.
Alarm mode	The LED display shows ten alarm events in the past in the order of occurrence.
“H” mode	Used to specify various parameters related to the system. Normally, users need not set the “H” mode parameters.

### 10.2.2 Shift between individual modes

You can shift between individual modes as shown below. For details on operating procedures, refer to the description for each mode.




## 10.3 Monitor Mode Display

### 10.3.1 Monitor mode display items


Mode	Monitor item	Unit	Description
n00	Pressure command voltage (Pi)	[V]	Displays a pressure command input voltage to the AI1 terminal. (Display range: 0.00 to 9.99)
n01	Flow rate command voltage (Qi)	[V]	Displays a flow rate command input voltage to the AI2 terminal. (Display range: 0.00 to 9.99)
n02	Pressure monitor voltage (Po)	[V]	Displays an output voltage to the AO1 terminal. (Display range: 0.00 to 9.99)
n03	Flow rate monitor voltage (Qo)	[V]	Displays an output voltage to the AO2 terminal. (Display range: 0.00 to 9.99)
n04	Pressure command value (Pi)	[MPa]	Displays a pressure command input value.
n05	Flow rate command value (Qi)	[ $\times 10 \text{ min}^{-1}$ ]	Displays a flow rate command input value as a motor rotation speed.
n06	Actual flow rate	[L/min]	Displays a theoretical flow rate value by multiplication of "motor rotation speed $\times$ pump volume".
n07	Actual rotation speed	[ $\times 10 \text{ min}^{-1}$ ]	Displays a motor rotation speed.
n08	Digital I/O signal status	–	Displays digital input/output status. For indication of each signal status, see the figure below.
n09	Regenerative load ratio	%	Displays the regenerative resistor's load ratio. When a specified time elapses under 25% or higher load, the alarm is activated to stop the unit.
n10	(Unused)	–	–
n11	Motor load ratio	%	Displays a motor load ratio. "100%" indicates the rated load of the motor. When the load ratio reaches 110%, the alarm is activated to stop the unit.
n12	Controller load ratio	%	Displays a controller load ratio. "100%" indicates the rated load of the controller. When the load ratio reaches 120%, the alarm is activated to stop the unit.
n13 (*1)	Software type	–	Displays a software type.
n14 (*1)	Software version	–	Displays a software version.

(\*1): Displayed for software revision No. "28" or subsequent number. For details, refer to "3.1.2 Manufacturing No."

DIO status indication for "n08: DIO monitor"




Example) When DI1 is ON:




DI1 (1st bit)

Example) When DO4 and DO7 are ON:



DO4 (1st bit) and DO7 (4th bit) are simultaneously ON.  
⇒ 9 (Hexadecimal number display)

### 10.3.2 Operation in the monitor mode



- [1] Press the  key in the normal mode. The displays will shift to the monitor mode.
- [2] Select a data number to be displayed with the  or  key. During selection of a data number, the display blinks.
- [3] Press the  key to register the data number. The selected number is displayed.
- [4] If you press the ,  or  key, you will return to the data number selection step.


## 10.4 Setting Mode Display

### 10.4.1 Setting mode display items

No.	Code	Name	Description
P00	DI_A	Start/stop signal switching	0: When the input signal turns ON, the motor starts running.(When the signal turns OFF, the motor stops.) 1: When the input signal turns OFF, the motor starts running.
P01	SW_L	(System reserved)	(Unused)
P02	T_SW	(System reserved)	(Unused)
P03	K_RT	Regenerative load command ratio	Motor protection constant for motor reverse rotation
P04	INIF	Initialize	When this parameter is set at "1", all parameters will be reset to the default settings when the power supply is turned OFF and then turned ON again.
P05	VMAX	Input command voltage scaling value	Input command voltage scaling value
P06	PMAX	Pressure command scaling value	Pressure setting corresponding to the maximum pressure command ( $P_i = VMAX [V]$ )
P07	QMAX	Flow rate command scaling value	Flow rate setting corresponding to the maximum flow rate command ( $Q_i = VMAX [V]$ )
P08	P_UG	Pressure rising gain	When a pressure error is a positive value ( $P_e = P_i - P_o > 0$ ), this gain is active.
P09	P_DG	Pressure falling gain	When a pressure error is a negative value ( $P_e = P_i - P_o < 0$ ), this gain is active.
P10	Q_UG	Flow rate rising gain	When a flow rate error is a positive value ( $Q_e = Q_i - Q_o > 0$ ), this gain is active.
P11	Q_DG	Flow rate falling gain	When a flow rate error is a negative value ( $Q_e = Q_i - Q_o < 0$ ), this gain is active.
P12	SC_L	Surge pressure detection level	Surge pressure detection level
P13	SC_G	Surge pressure reduction gain	When this parameter is set larger, surge pressure can be suppressed.
P14	D_TM	Delay time setting	Wait time until pump startup after pressure/flow rate command input in standby status
P15	BIAS	Bias pressure	Pressure command value in standby status
P16	V_KD	Speed differential gain	Speed differential gain
P17	P_P1	Pressure proportional gain [for DH range]	When a pressure error is in the DH control range, this proportional gain is active.
P18	P_P2	Pressure proportional gain [for override range]	When a pressure error is in the override range, this proportional gain is active.
P19	P_I1	Pressure integral time [for small pressure error]	When a pressure error is a small positive value, this integral time (gain) is active.
P20	P_I2	Pressure integral time [for large positive pressure error]	When a pressure error is a large positive value, this integral time (gain) is active.
P21	P_I3	Pressure integral time [for negative pressure error]	When a pressure error is a negative value, this integral time (gain) is active.
P22	P_UT	Pressure rising time constant	Time constant of the internal command rising ramp filter relative to a stepped change in pressure command
P23	P_DT	Pressure falling time constant	Time constant of the internal command falling ramp filter relative to a stepped change in pressure command
P24	P_SP	Cutoff width	P-Q control override (cutoff) pressure width
P25	BR_R	Regenerative resistance value	Regenerative resistance value
P26	BR_W	Regenerative resistance capacity	Regenerative resistance capacity
P27	AR_A	(System reserved)	(Unused)

No.	Code	Name	Description
P28	ARFS	(System reserved)	(Unused)
P29	WN_L	Overload warning output judgment level	“L49: Overload warning” judgment level
P30	DO_S	Digital output function select	Select digital output function The alarm code output can be selected

10.4.2 Operation in the setting mode



- [1] Press the and keys simultaneously in the normal mode. After approx. 2 seconds, the display will shift to the setting mode.
- [2] Select a data number to be displayed with the or key. During selection of a data number, the display blinks.
- [3] Press the key to register the data number. The selected number is displayed.
- [4] To change the set value, increment or decrement the value with the or key.
- [5] Press the key to register the set value. Then, you will return to the data number selection step.

## 10.5 “H” Mode

The “H” mode parameters are related to the system. Normally, users need not set these parameters.

### 10.5.1 “H” mode display items


No.	Code	Name	Description
H00 (*1)		Current command ratio display	100 [%]: Maximum current of the controller
H01 (*1)	–	Motor load ratio display	100 [%]: Motor rated current
H02 (*1)	–	(Unused)	–
H03 (*1)	–	Motor thermo temperature display	Motor thermo temperature
H04 (*1)	–	Fin thermo temperature display	Controller radiation fin temperature
H05 (*1)	–	Power supply voltage display	Main circuit DC voltage
H06 (*1)	–	(Unused)	–
H07 (*1)	–	(Unused)	–
H08 (*1)	–	(Unused)	–
H09	L_G_	Load gain	100% = 7 MPa, 5000 rpm
H10	V_KP	Speed proportional gain	Speed proportional gain
H11	V_KI	Speed integral gain	Speed integral gain
H12	V_KD	Speed differential gain	Speed differential gain
(*6)	P_FF	Pressure feed-forward gain	Motor current correction during pressure rise
H13	V_SP	Gain schedule point	Gain schedule point
H14	AC_M	(Unused)	(Unused)
H15 (*2)	Q_EV	Volume efficiency correction	Pump volume efficiency correction
H16	POCH	Pressure monitor channel	Digital output terminal AO1 output data
H17	QOCH	Flow rate monitor channel	Digital output terminal AO2 output data
H18	V_NP	Speed proportional neutral gain	Speed proportional neutral gain
H19	E_TM	Motor startup error judgment time	Motor startup error judgment time
H20	FLOC	Panel setting change lock	0: Enables panel setup change 1: Disables panel setup change
H21 (*4)	PI_Z	PI Zero	Pressure command (Pi) zero point
H22 (*4)	PI_G	PI Gain	Pressure command (Pi) gain
H23 (*4)	QI_Z	QI Zero	Flow rate command (Qi) zero point
H24 (*4)	QI_G	QI Gain	Flow rate command (Qi) gain
H25 (*4)	PO_Z	PO Zero	Pressure monitor (Po) zero point
H26 (*4)	PO_G	PO Gain	Pressure monitor (Po) gain
H27 (*4)	QO_Z	QO Zero	Flow rate monitor (Qo) zero point
H28 (*4)	QO_G	QO Gain	Flow rate monitor (Qo) gain
H29	ZP10	Z phase Plus 10 value	Z phase Plus 10 value

No.	Code	Name	Description
H30 (*3)	PS_G	Pressure sensor gain	Pressure sensor gain
H31	DR_L	Dry operation judgment level	Dry operation judgment standard pressure
H32	DR_T	Dry operation judgment time	Dry operation judgment time
H33	PNG1	(Unused)	(Unused)
H34	PNG2	(Unused)	(Unused)
H35	DRTN	Bias dry operation judgment time	Dry operation judgment time in standby status
H36 - H46	-	System reserved	-
H47	DI_L	Pump capacity selection signal switching	Switch the logic of the signal that determine the pump operating conditions. 0: Pump confluence operation when the signal is OFF 1: Pump confluence operation when the signal is ON
H48	L_G2	Load Gain 2	The minimum output value adjusted by the load automatic adjustment feature
H49	M_TI	Motor load automatic adjustment constant	Constant for motor load automatic adjustment
H50	A_TI	Controller load automatic adjustment constant	Constant for controller load automatic adjustment
H51	L_GB	Load Gain Backup	Load automatic adjustment value when the power supply is cut off the last time

- (\*1) For value monitoring only
- (\*2) To correct differences in pump volume efficiency among individual units, the default setting has been adjusted for each unit.
- (\*3) To correct differences among individual pressure sensors and controllers, the default setting has been adjusted for each unit. The pressure sensor zero point is automatically adjusted, regardless of a parameter setting.
- (\*4) To correct differences among individual controllers, the default setting has been adjusted for each unit.
- (\*5) If “H20” (Panel setting change lock) is set to “1”, parameter change operation through the controller panel is prohibited.  
Please set the parameter by machine maker to prohibit end users from changing parameters through the controller panel.

<b>IMPORTANT</b>	Do not change the default settings of the “system reserved” parameters. If the default settings are changed, it may result in unexpected operation of the hydraulic unit.
------------------	--

## 10.5.2 Operation in the “H” mode



## NOTE

For the items indicated as (\*1) in [ 10.5.1“H” mode display items], you can only view a set value, and cannot change the set value by conducting the (4) and (5) steps below.


- [1] Press and hold the ,  and  keys simultaneously in the normal mode. After approx. 2 seconds, the display will shift to the “H” mode.
- [2] Select a data number to be displayed with the  or  key. During selection of a data number, the display blinks.
- [3] Press the  key to register the data number. The selected number is displayed.
- [4] To change the set value, increment or decrement the value with the  or  key.
- [5] Press the  key to register the set value. Then, you will return to the data number selection step.

## 10.6 Alarm Mode Display

## 10.6.1 Alarm list

For details of each alarm, refer to “14.1.1 Description of alarms”.

### 10.6.2 Operation in the alarm mode



- [1] Press and hold the and keys simultaneously in the normal mode. After approx. 2 seconds, the displays will shift to the alarm mode.
- [2] Select an alarm record number to be displayed with the or key. During selection of an alarm record number, the display blinks.  
“A00” indicates the latest alarm. Alarms in the past are indicated as “A01 → A02 →” in sequence from the newest one.
- [3] Press the key to register the alarm record number. The corresponding alarm code and the power-ON count at occurrence of the alarm are alternately displayed.

NOTE	If the power-ON count exceeds “650”, it will be cleared to “0”.
------	---

- [4] If you press the , or key, you will return to the alarm record number selection step.

## Chapter 11 Trial Run/Operation



- In preparation for a case of emergency, connect wiring so that the power supply can be immediately turned OFF.
- If this hydraulic unit operates in an unexpected way, ensure safety before starting operation.
- Before turning ON the power supply, attach the motor and controller terminal block covers. Do not remove the controller terminal block covers while the power supply is ON. Failure to observe this instruction may result in an electric shock.

### 11.1 Running power ON

Before turning ON the power supply, be sure to check the following points:

- Check if the hydraulic unit is properly installed. (Refer to “7.2 Installation of Motor Pump”, “7.3 Installation of the controller”.)
- Check if the piping is properly connected. (Refer to “Chapter 8 Hydraulic Piping”.)
- Check if the wiring is properly connected. (Refer to “Chapter 9 Electric Wiring”.)
- Check if the digital input signal is OFF. (Refer to “11.2.4 [P00:DI\_A] ”.)
- Check if the power supply voltage is normal. (Refer to “3.2 Specifications”.)

### 11.2 Description of Parameters

#### 11.2.1 [P05:VMAX] Input command voltage scaling value

Specify a maximum value of command voltage input from the main machine. The input voltage is converted into a command value based on the settings of this parameter and [P06: PMAX] and [P07: QMAX] (“11.2.2”).

Pressure and flow rate monitor voltages are also converted by using these parameters.

No.	Code	Parameter name	Setting range	Unit
P05	VMAX	Input command voltage scaling value	0 –10	V


NOTE	<p>If the unit cannot operate at the maximum pressure and the maximum flow rate, perform the following procedure:</p> <ol style="list-style-type: none"> <li>1) With maximum command voltage input from the main machine, check the monitor values of “n00: Pressure command voltage” and “n01: Flow rate command voltage” to verify the input voltage recognized by the unit.</li> <li>2) Specify the voltage displayed in the monitor as “P05: Input command voltage scaling value”.</li> </ol>
------	---

#### 11.2.2 [P06:PMAX], [P07:QMAX] Pressure/flow rate command scaling


Specify the pressure command value and flow rate command value corresponding to the pressure/flow rate command voltage of “P05: Input command voltage scaling value”.

Based on the settings of these parameters and the setting of “11.2.1 Input command voltage scaling value”, an input voltage is converted into a command value as shown below: Pressure and flow rate monitor voltages are also converted as shown below.

■ command voltage



■ Monitor voltage conversion



No.	Code	Parameter name	Setting range	Unit
P06	PMAX	Pressure command scaling value	*	MPa
P07	QMAX	Flow rate command scaling value	*	×10min <sup>-1</sup>

\* The setting range varies on the unit model.

<b>IMPORTANT</b>	<p>The flow rate command scaling value is defined as motor rotation speed.                  The default setting has been adjusted depending on differences among individual pumps, so that the maximum value of actual flow rate conforms to the specifications.                  If you change the maximum flow rate, calculate a set value of this parameter so as to ensure accuracy of actual flow rate, as described below:</p> <p>Example)                  When the maximum flow rate is 80 L/min relative to the maximum flow rate setting of 70 L/min,</p> <p style="text-align: center;">“P07: Flow rate scaling” set value = “P07: Flow rate scaling” default setting × (70/80)</p>
------------------	--

<b>NOTE</b>	<p>The pressure command and flow rate command relative to a command voltage are calculated as shown above. Therefore, if the command voltage input from the main machine is not linear, intended characteristics may not be obtained.                  While monitoring an input command voltage with “n00: Pressure command voltage” and “n01: Flow rate command voltage”, verify and adjust the linearity of the command voltage from the main machine.</p>
-------------	---

### 11.2.3 [P15:BIAS] Pressure command in standby status

If the following conditions are simultaneously satisfied, it is defined as standby status.


- ◆ Pressure command is less than “P15: Bias pressure”.

- ◆ Flow rate:

Model: SUT00D	Flow rate condition
8021	Flow ratecommand < “P07: Flow rate command scaling value”×0.08

No.	Code	Name	Setting range	Unit
P15	BIAS	Bias pressure	0–20	0.1MPa

If both pressure command and flow rate command input voltages are low, the hydraulic unit becomes standby status. In this condition, the control pressure does not conform to the pressure command input value. The pressure command in standby status is limited depending on this parameter setting, as shown on the right.



<b>IMPORTANT</b>	<ul style="list-style-type: none"> <li>● When a solenoid selector valve is used in the hydraulic circuit, switching response may be delayed if the pilot pressure is too low. In this case, increase the setting of this parameter so as to ensure sufficient pilot pressure in standby status.</li> <li>● When both “Pi” and “Qi” are set at 0 [V], the hydraulic unit is in standby status, to be controlled at the pressure specified in this parameter. To execute pressure control at low pressure (e.g. for clamping a die at low pressure), set the flow rate command value 15% or higher than the “QMAX” setting. With this setting, the hydraulic unit does not become standby status, enabling pressure control at pressure that does not exceed the bias pressure.</li> </ul>
------------------	--

### 11.2.4 [P00:DI\_A] Start/stop signal switching

The motor start/stop command is activated by an input signal to the digital input signal terminal (DI1).

No.	Code	Name	Setting range	Unit
P00	DI_A	Start/stop signal switching	0: When the input signal turns ON, the motor starts running. 1: When the input signal turns OFF, the motor starts running.	–

Set value	DI1 terminal status	
	OFF	ON
0	Pump stop	Pump start
1	Pump start	Pump stop



- If the pump is frequently started and stopped by turning ON/OFF the power supply, the controller service life is shortened. To start/stop the pump, use the digital input signal (DI1) (except for an emergency case).

<b>NOTE</b>	To run the hydraulic unit without using the digital input signal, set this parameter to “1”. With this setting, the hydraulic unit automatically starts when the power supply is turned ON.
-------------	---

### 11.2.5 [P25:BR\_R], [P26:BR\_W] Regenerative resistor setting

Normally, use these parameters at the default settings.

If a regenerative resistor is prepared by user, set the following parameters to define resistance and capacity of the regenerative resistor being used.

No.	Code	Name	Setting range	Unit
P25	BR_R	Regenerative resistance value	1-999	Ω
P26	BR_W	Regenerative resistance capacity	0.01-99.9	kW



- Check specifications of the regenerative resistor connected to the controller, and set this parameter at a proper value. An improper setting of this parameter may result in abnormal heating of the regenerative register, or damage to the controller.
- To connect several regenerative resistors in parallel, select regenerative resistors so that all resistors provide equal resistance and capacity. Failure to observe this instruction may result in abnormal heating of the regenerative registers.
- Select regenerative resistors so that the resultant resistance of the regenerative resistors connected to the controller conforms to the default setting of the “P25: Regenerative resistance value” parameter. Failure to observe this instruction may result in damage to the controller. For details, refer to “9.2.2 Regenerative breaking resistor”.

<b>IMPORTANT</b>	<ul style="list-style-type: none"> <li>● Set the resultant resistance of the regenerative resistors connected to the controller. (Example) When three resistors of 500 W and 30 Ω are connected in parallel:  <div style="text-align: center; margin: 10px 0;"> <math display="block">\text{Resultant resistance} = 10 \Omega \left[ \frac{1}{\frac{1}{30[\Omega]} + \frac{1}{30[\Omega]} + \frac{1}{30[\Omega]}} \right] = 10 [\Omega]</math> </div> <p style="text-align: center;">Resultant capacity = 1.5 kW (500 W × 3 resistors in parallel = 1.5 kW)                      Therefore, set [P25: BR_R] at “10 [W]”, and set [P26: BR_W] at “1.50 [kW]”.</p> </li> <li>● The setting of this parameter becomes active when the power supply is turned ON again.</li> </ul>
------------------	--


### 11.2.6 [P29:WN\_L] Overload warning output judgment level

Specify a judgment value for “L49: Overload warning output”.

If a load value is judged as overload warning status, “L49: Overload warning” is indicated on the panel, and the digital output signal on the DO4 terminal is turned ON.

No.	Code	Name	Setting range	Unit
P29	WN_L	Overload warning output judgment level	0–120	%

\* If the overload warning indication and output are not required, set this parameter at “120”.



### 11.2.7 [H47:DI\_L] Pump capacity selection signal switching


By inputting confluence / single switching signal into controller, the PQ characteristics can be chosen in accordance with the pump state. By setting this parameter, the logic of the DIN5 signal in confluence can be configured.

H47: Pump capacity selection signal switching	DIN5 Pump capacity selection signal	Pump state
0	OFF	confluence
	ON	single
1	OFF	single
	ON	confluence

**11.3 Confirmation of linearity of command voltage Pi/Qi**

When this hydraulic unit is used as a substitute for a proportional valve system, linearity may not be provided for the pressure/flow rate command voltage on the molding machine.

This hydraulic unit executes pressure/flow rate control in proportion to a command voltage value, as shown below:



Therefore, adjust the command value relative to each pressure/flow rate setting on the molding machine to ensure linearity, by referring to the table below:

◆ Example of command voltage adjustment value on molding machine

Pressure/flow rate set value [%]	Voltage adjustment value [V]
0	0.00±0.01
20	2.00±0.01
40	4.00±0.01
60	6.00±0.01
80	8.00±0.01
100	10.00±0.01

## 11.4 Pump Operation/Air Purge

- 1) Before operating this product, connect another pump and filter for flushing operation to the tank and piping circuit of the molding machine, to flush the tank and piping thoroughly (for at least two hours).  
After flushing operation, check the filter element for a foreign object.
- 2) Replace the hydraulic oil with new oil, and fill the tank with a specified level of hydraulic oil. After completion of piping and electrical wiring, conduct a trial run of the SUT pump.  
Check the electrical wiring with the connection diagram to ensure that the electrical parts (e.g. noise filter, DC reactor) are properly connected.
- 3) Turn ON the power supply for the molding machine, and make the pump ready for operation with the start/stop signal.  
After setting the pressure command voltage (Pi) and flow rate command voltage (Qi) parameters to “0.0 V”, start the pump in the unload operation mode.  
Check for abnormal sound during pump operation, and verify that the pressure increases to the unload pressure with the display of the controller panel.
- 4) Verify cooling air from the motor cooling fan. Because the cooling fan is the single-phase AC type, the fan rotates in a fixed direction.
- 5) Check hydraulic operations of the injection table forward/backward movement and the ejector operation.
- 6) Turn ON the solenoid valve, and set the pressure (Pi) to 1 to 2 MPa, and set the flow rate (Qi) to 10 to 20%.  
While moving the injection table or ejector in the full stroke through “manual operation” under low pressure and at a low speed, check for an oil leak from the piping, and abnormal sound from the pump.  
If hunting occurs in the middle of the injection table forward/backward movement, it may be caused by air contained in hydraulic oil, or the pump may be running in the pressure override range because of high load pressure. In this case, reduce the pressure setting (Pi) a little (to approx. 50% of P<sub>MAX</sub>), and check the operating condition while running the pump in the flow rate control mode.  
While repeating the injection table forward/backward movement in the full stroke several times, release air from the circuit.
- 7) Verify that the molding machine enables injection and mold operation without resin.  
In the same manner, operate each unit of the molding machine in the full stroke at the lowest pressure and speed (Pi and Qi: 20 to 30%) to release air from each cylinder and circuit. Also, check for a loose connection or oil leak in the piping, and correct a defective part.  
If hunting occurs during operation, change the pressure setting so that it is higher than the specified load pressure to run the pump in the flow rate control mode.  
If hunting persists even in the flow rate control mode, adjust the following parameters:
  - Reduce “P\_P2” from the default setting.
  - Increase “P\_I1” from the default setting.
 It is recommended that you should record the parameter settings before change.
- 8) Continue to operate each cylinder until air release from the circuit is completed.  
Note that the “E17: Motor electronic thermal” alarm may be activated, if the pump is kept running in the high-pressure DH status for a specified time. If this alarm is activated, turn OFF the power supply once, and then turn it ON again, and run the pump in a condition that does not cause overload.

## 11.5 Management of parameters

When a machine equipped with the SUT series undergoes adjustment before shipment from the main machine manufacturer, and if a parameter setting is changed from the default value, the parameter data that has been changed by the machine manufacturer must be kept in record for the purpose of machine maintenance.

If a parameter change from the main machine manufacturer' settings may cause a trouble, parameter change operation through the controller panel is prohibited by the following procedure:

- About "H20: Panel setting change lock"

If "H20" (Panel setting change lock) is set to "1", parameter change operation through the controller panel is prohibited. To unlock the parameter change lock status, set this parameter to "0".

For the "H20" parameter setting change procedure, refer to "10.5.2 Operation in the "H" mode".

## Chapter 12 Gain Adjustment


To adjust response time and stability in pressure/flow rate control, set the parameters described in this chapter.

IMPORTANT	<ul style="list-style-type: none"> <li>● Before changing a parameter, record a preset value. It is required when you restore the unit to the original condition in the middle of adjustment.</li> <li>● After a parameter is changed, the changed value should be also kept in record.</li> </ul>
-----------	---

### 12.1 [P08: P\_UG] Pressure Rising Gain

Adjust the control pressure ( $P_o$ ) rising response relative to rising of the pressure command signal ( $P_i$ ).

If this parameter is set larger, the response time is shortened as shown on the right, but it easily results in overshoot.




No.	Code	Name	Setting range	Unit
P08	P_UG	Pressure rising gain	1-999	-

### 12.2 [P09: P\_DG] Pressure Falling Gain

Adjust the control pressure ( $P_o$ ) falling response relative to falling of the pressure command signal ( $P_i$ ).

If this parameter is set larger, the response time is shortened as shown on the right, but it easily results in undershoot.




No.	Code	Name	Setting range	Unit
P09	P_DG	Pressure falling gain	1-999	-

### 12.3 [P10: Q\_UG] Flow Rate Rising Gain

Adjust the control flow rate ( $Q_o$ ) rising response relative to rising of the flow rate command signal ( $Q_i$ ).


If this parameter is set larger, the response time is shortened as shown on the right, but it easily results in overshoot.



No.	Code	Name	Setting range	Unit
P10	Q_UG	Flow Rate Rising Gain	1-200	-

**12.4 [P11: Q\_DG] Flow Rate Falling Gain**


Adjust the control flow rate ( $Q_o$ ) falling response relative to falling of the flow rate command signal ( $Q_i$ ).  
 If this parameter is set larger, the response time is shortened as shown on the right, but it easily results in undershoot.



No.	Code	Name	Setting range	Unit
P11	Q_DG	Flow Rate Falling Gain	1-200	-

**12.5 [P13: SC\_G] Surge Pressure Reduction Gain**

Reduce surge of control pressure ( $P_o$ ) relative to rising of the pressure command signal ( $P_i$ ).  
 If this parameter is set larger, the surge pressure can be suppressed as shown on the right, but the response time becomes long.




No.	Code	Name	Setting range	Unit
P13	SC_G	Surge Pressure Reduction Gain	0-999	-

**12.6 [P14: D\_TM] Delay time setting**


Setting this parameter can delay start of pump response when the pump starts up from the hydraulic unit standby status.

No.	Code	Name	Setting range	Unit
P14	D_TM	Delay time setting	0-100	ms



If the pump makes response upon rising of the command voltage from the standby status, the pump starts up before switching operation of the solenoid valve in the hydraulic circuit is completed. This may cause an abrupt change in pressure and flow rate, resulting in a shock as “Po” and “Qo” shown on the right.

Setting this parameter enables the pump to start up after the solenoid valve is completely switched, resulting in a smooth response waveform (shockless control) as “Po2” and “Qo2” shown in the right.




**NOTE** • This parameter is active only for response from standby status.

## 12.7 Pressure Proportional Gain/Integral Time

### 12.7.1 Control response trace

The following chart plots trace of pressure and flow rate response until the hydraulic unit becomes pressure-holding status from standby status according to “Pi” and “Qi” command voltages.

When the load pressure “Po” reaches the value specified in “P24: P\_SP” relative to “Pi” and “Qi” command values, the hydraulic unit decreases flow rate, and executes control so that “Po” and “Qo” become the target values, as shown below.



In each status, the hydraulic unit autonomously selects and changes the proportional gain and integral time according to the table below.

Area No.	Status	Proportional gain		Integral time	
		No.	Code	No.	Code
(1)	Standby status → Acceleration	P08	P_UG	P20	P_I2
(2)	(Pressure command value – “P24: Pressure cutoff”) < Current pressure	P18	P_P2	P19	P_I1
(3)	Overshoot	P09	P_DG	P21	P_I3
(4)	Pressure control mode	P17	P_P1	P19	P_I1

NOTE	<ul style="list-style-type: none"> <li>When selected proportional gain and integral time parameters are changed, the gain will be smoothly and continuously changed to prevent unstable operation.</li> <li>If the “P24: Pressure cutoff” setting is too small, pressure override occurs, resulting in unstable operation.</li> </ul>
------	---

### 12.7.2 [P17:P\_P1],[P18:P\_P2] Pressure Proportional Gain

Generally, as this parameter is set larger, the response is improved. However, if the set value is too large, overshoot or undershoot may occur.

No.	Code	Name	Setting range	Unit
P17	P_P1	Pressure proportional gain [for DH range]	1–999	–
P18	P_P2	Pressure proportional gain [for override range]	1–999	–

### 12.7.3 [P19:P\_I1],[P20:P\_I2],[P21:P\_I3] Pressure Integral Time

If this parameter is specified, the pump enables response even to a minute input. Generally, as this parameter is set smaller, the response is improved. However, if the set value is too small, overshoot or undershoot may occur.

No.	Code	Name	Setting range	Unit
P19	P_I1	Pressure integral time [for small pressure error]	10–999	–
P20	P_I2	Pressure integral time [for large positive pressure error]	10–999	–
P21	P_I3	Pressure integral time [for negative pressure error]	10–999	–

### 12.7.4 [P24:P\_SP] Cutoff width

When the load pressure “Po” reaches the value specified in “P24: P\_SP” relative to “Pi” and “Qi” command values, this hydraulic unit executes control so that flow rate gradually decreases.

If this parameter is set to a smaller value, operation in the pressure override range becomes unstable.


No.	Code	Name	Setting range	Unit
P24	P_SP	Cutoff width	0–100	0.1MPa

## 12.8 Pressure Proportional Gain/Integral Time

According to the proportional gain setting, the hydraulic unit can adjust an amount of correction in proportion to a control error.

If the proportional gain parameter is set larger, the response time is shortened (as “Po1” in the figure), but surge pressure easily occurs.


If the proportional gain parameter is set smaller, surge pressure can be suppressed (as “Po2” in the figure), but the response time becomes longer.



According to the integral time setting, the hydraulic unit can adjust an amount of correction by totalizing control errors in the specified time.

If the integral time parameter is set smaller, a quicker response is enabled relative to a control error (as “Po3” in the figure), but surge pressure easily occurs.


If the integral time parameter is set longer, surge pressure can be suppressed (as “Po4” in the figure), but the response time becomes longer.



As described above, when the proportional gain setting is large and the integral time setting is small, a response time relative to a command is shortened, but operating condition easily becomes unstable (e.g. hunting occurs.) because the amount of correction becomes large. While monitoring actual operating conditions, change the proportional gain and integral time settings, to adjust the response time and stability.

## 12.9 Pressure Rising Time Constant/Pressure Falling Time Constant

If the “Pressure rising time constant” and “Pressure falling time constant” parameters are specified, the internal pressure command and flow rate command can be changed in a ramp form relative to a command voltage change in a stepped form. This function can prevent overshoot and undershoot, and reduce shock during acceleration and during stop.



For the pressure rising time constant, specify a time required to increase a pressure command from “0” to “P06: PMAX”.

For the pressure falling time constant, specify a time required to decrease a pressure command from “P06: PMAX” to “0”.

No.	Code	Name	Setting range	Unit
P22	P_UT	Pressure rising time constant	0-200	ms
P23	P_DT	Pressure falling time constant	0-200	ms

**NOTE** If high response is required, set the ramp response time of the molding machine to “0” before adjusting the above parameters.

## 12.10 Speed Differential Gain

Differentiation of motor rotation speed provides damping effect, resulting in stable response.

Normally, this parameter should be retained as the default setting. User need not change the set value. To change the default setting, adjust it in a range of approx. 10 to 20. Setting a larger value increases the speed differentiation effect.

No.	Code	Name	Setting range	Unit
P16	V_KD	Speed differential gain	0-100	-

## Chapter 13 Autonomous Switching Function

The pump autonomous switching system in the super unit is a double pump system. Two fixed capacity pumps (a large one and a small one) can be autonomously switched to confluence / single mode by a switching valve.

Its main characteristics are as follows.

- When the flow rate is required, the large capacity pump and small capacity pump work together with a high-speed rotation. On the other hand, in pressure holding time the flow rate is small, only the small capacity pump rotates at a low speed. In this way, significant energy saving is realized.
- Pumps can be autonomously switched to the confluence / single mode in this system. So it is easy to use, because the timing adjustment for pump switching is unnecessary.
- Because high pressure and high flow rate can be realized by switching pumps, the capacity of controller and motor becomes smaller, compared with the conventional. So it is possible to reduce the cost.

### 13.1 Autonomous switching setting

In order to use the autonomous switching function, it is necessary to wire and change parameters below.

#### 13.1.1 Wire for autonomous switching

It is necessary to change the following wire, according to "Chapter 15 wiring diagram".

	Digital output selection wiring (Described in Chapter 15 Wiring diagram)	Autonomous switching wiring
DO3	(Unused)	Pump solenoid valve autonomous switching signal Output a signal to autonomously switch the solenoid valve. The solenoid valve can be switched via a relay by a signal output.
DI5	Pump capacity switching input Input the same signal as the pump solenoid valve switching signal. By the controller, the input signal controls the confluence / single.	(Unused)
Pump solenoid valve switching	Switch according to the timing main machine side	Switch by DO3 output The power supply of solenoid valve is supplied from the main machine side
Wiring diagram		

#### 13.1.2 Change "H54: pump switching condition"

Please change "H54: pump switching condition" from default settings "0: Digital input selection" to "1: Autonomous switching". The changed parameter will be applied, when turn ON the supply power again.

### 13.2 Additional parameters

- Setting mode Display item list

No.	Symbol	Name	Remarks
P36	CS_P	Switching to single pressure offset	Switch the pump from confluence to single mode by setting the pressure conditions. Set the difference value of the smaller one of the following value. If the pressure exceeds this setting value, the pump will switch to single mode. <input type="checkbox"/> "P40: pump confluence maximum pressure" <input type="checkbox"/> Pressure command value When the cylinder reaches the end, and the pressure becomes higher than the setting value in this parameter, it can quickly switch to the single mode. If the value is set to 0, switching to the single mode by this pressure conditions is invalid.
P37	CS_N	Switching to single rotational speed offset	Switch the pump from confluence to single mode by setting the rotational speed conditions. Set the difference value of the smaller one of the following value. If the rotational speed becomes less than this setting value, the pump will switch to single mode. <input type="checkbox"/> "P39: pump single maximum flow rate" <input type="checkbox"/> Flow rate command value
P38	CD_P	Switching to confluence pressure offset	Switch the pump from single to confluence mode by setting the difference value of the pressure command value. Set the difference value of the smaller one of the following value. If the pressure is less than this setting value, and the flow rate is higher than "P42: Single pump maximum flow", the pump will switch to confluence mode. <input type="checkbox"/> "P40: pump confluence maximum pressure" <input type="checkbox"/> Pressure command value
P39	QH__	Pump single maximum flow rate	Set the maximum flow rate of the pump at the single mode. It is a theoretical flow rate, which is calculated through the motor speed. If the value is set to 0, switching to the single mode will become invalid.
P40	PL__	Pump confluence maximum pressure	Set the maximum pressure of the pump at the confluence mode. The pressure command value of the pump at the confluence mode is limited by this parameter. If the value is set to 0, switching to the confluence mode will become invalid.

■ Setting mode Factory default list

No.	Name	Range, Unit	Factory default value		
			8021	13021	15021
P36 (*1)	Switching to single pressure offset	0 - 10.0 [MPa]	1.0	1.0	1.0
P37 (*1)	Switching to single rotational speed offset	0 - 999 [min <sup>-1</sup> ]	100	100	100
P38 (*1)	Switching to confluence pressure offset	0 - 10.0 [MPa]	1.0	1.0	1.0
P39 (*1)	Pump single maximum flow rate	Shown on the right [L/min]	38.5 (0~38.5)	47.9 (0~47.9)	70.9 (0~70.9)
P40 (*1)	Pump confluence maximum pressure	Shown on the right [MPa]	17.6 (0~15)	20.6 (0~15.1)	17.6 (0~16.7)

(\*1): "H54: pump switching condition" will be valid, only when it chooses the "1: Autonomous switching".

■ H mode Item list

No.	Symbol	Name	Remarks
H52	CS_T	Switching to single holding time	Immediately after switching to single mode from confluence mode, the holding time at single state can be set. And in this time, it becomes impossible to switch the pump to confluence mode from single mode. Because some main machine hardware factors, such as load volume, it will take time to stabilize when switching from confluence mode to single mode. In this case, please set this parameter to prevent hunting.
H53	CD_T	Switching to confluence	Immediately after switching to confluence mode from single mode, the holding

No.	Symbol	Name	Remarks
		holding time	time at confluence mode can be set. And in this time, it becomes impossible to switch the pump to single mode from confluence mode. Because some main machine hardware factors, such as load volume, it will take time to stabilize when switching from single mode to confluence mode. In this case, please set this parameter to prevent hunting.
H54	P_C_	Pump switching condition	Choose whether the pump switches autonomously according to the unit, or according to the command from the main machine. The changed parameter will be applied, when turn ON the supply power again.
H55	SD_T	Pump confluence holding time when startup	The maintain time of the confluence mode after starting from the standby state or stop state.

■ H mode Factory default list

No.	Name	Range, Unit	Factory default value		
			8021	13021	15021
H52 (*1)	Switching to single holding time	0 - 9.99 [sec]	0.3	0.3	0.3
H53 (*1)	Switching to confluence holding time	0 - 9.99 [sec]	0.3	0.3	0.3
H54 (*2)	Pump switching condition	0 : Digital input switching 1 : Autonomous switching	0	0	0
H55 (*1)	Pump confluence holding time when startup	0.01 - 9.99 [sec]	0.1	0.1	0.1

(\*1): "H54: pump switching condition" will be valid, only when it chooses the "1: Autonomous switching".

(\*2): The changed parameter will be applied, when turn ON the supply power again.


### 13.2.1 Confluence → single switching parameters configuration

By the following parameters, the switching conditions from confluence mode to single mode can be set.

No.	Symbol	Name	Range	Factory default value	Unit
P36	CS_P	Switching to single pressure offset	0 - 10.0	1.0	MPa
P37	CS_N	Switching to single rotational speed offset	0 - 999	100	min <sup>-1</sup>
P39	QH_	Pump single maximum flow rate	*	*	L/min
P40	PL_	Pump confluence maximum pressure	*	*	MPa

\* For each model, the setting range and the factory setting are different.

The pump will be switched to single mode from confluence mode, if pressure & flow rate enter any of the shaded area below.



Note	<input type="checkbox"/> When the pressure command $p_i < \text{"P40: pump confluence maximum pressure"}$ The switching to single mode pressure condition is set by the offset from $p_i$ .  <input type="checkbox"/> When the flow rate command $q_i < \text{"P39: Pump single maximum flow rate"}$ If the rotation speed is less than $q_i - \text{"P37: Switching to single rotational speed offset"}$ , the pump will be switched to single mode.
------	---


### 13.2.2 Single → confluence switching parameters configuration

By the following parameters, the switching conditions from single mode to confluence mode can be set.

No.	Symbol	Name	Range	Factory default value	Unit
P38	CD_P	Switching to confluence pressure offset	0 - 10.0	1.0	MPa
P39	QH__	Pump single maximum flow rate	*	*	L/min
P40	PL__	Pump confluence maximum pressure	*	*	MPa

\* For each model, the setting range and the factory setting are different.

The pump will be switched to confluence mode from single mode, if pressure & flow rate enter any of the shaded area below.



Note	<ul style="list-style-type: none"> <li>When the pressure command <math>p_i &lt; \text{"P40: pump maximum pressure"}</math>                      The switching to confluence mode pressure condition is set by the offset from <math>p_i</math>.</li> </ul>
------	--

### 13.2.3 Other pump states

When an alarm occurs, or in stopped state, pump is selected as shown in the table below in accordance with each state.

No	State	Pump state
1	Stopped	confluence
2	Alarm	confluence
3	Standby	confluence
4*	Startup	confluence

\* After starting from the standby state or stop state, the pump state will keep in confluence mode for a time determined by parameter H55 "Pump confluence holding time when startup".

### 13.2.4 Switching logic of the digital output signal

By setting the parameter "H47: Pump confluence signal switching", the output logic of the confluence / single mode determined by the digital output signal DOUT3 can be set.

Please set this parameter according to the logic of the solenoid valve.

No.	Symbol	Name	Range	Factory default value
H47	DI_L	Pump confluence signal switching	0 : Confluence when the signal is OFF 1 : Confluence when the signal is ON	1

H47 (DI_L) : Pump confluence signal switching	Pump State	DOUT3 : Pump capacity switching output
0	Confluence	OFF
	Single	ON
1	Single	OFF
	Confluence	ON

### 13.2.5 Example of the pump switching adjustment

When unexpected pump switching occurs, please adjust the parameters as follows.

■ Adjustment when switch from confluence to single

Example	Figure	Description
1		<p>If the operating point is near the intersection of the confluence PQ area and the single PQ area, the pump switching is likely to occur. By increasing "P37: Switching to single rotational speed offset", the difference value between the operating point and "rotational speed conditions of single switching" is expanded. In this way, it is possible to prevent unnecessary single mode switching.</p>
2		<p>If the pump is switched to single mode just because of an instant pressure surge, please increase "P36: Switching to single pressure offset". In this way, it is possible to prevent unnecessary single mode switching. In addition, if the value of "P36: Switching to single pressure offset" is set as 0, it will be disabled to switch to single mode by pressure conditions.</p>

No.	Symbol	Name	Range	Factory default value
P36	CS_P	Switching to single pressure offset	0 - 10.0[MPa]	1.0
P37	CS_N	Switching to single rotational speed offset	0 - 999[ $\text{min}^{-1}$ ]	100

■ Adjustment when switch from single to confluence

Example	Figure	Description
---------	--------	-------------

Example	Figure	Description
1		<p>If the operating point is near the intersection of the confluence PQ area and the single PQ area, the pump switching is likely to occur.</p> <p>By increasing " P38: Switching to confluence pressure offset ", the difference value between the operating point and the switching condition is expanded. In this way, it is possible to prevent unnecessary confluence mode switching.</p>

No.	Symbol	Name	Range	Factory default value
P38	CD_P	Switching to confluence pressure offset	0 - 10.0[MPa]	1.0

### 13.3 Pump confluence / single selection with a digital input signal

If the parameter "H54: Pump switching condition" is set to "0: Digital input selection", the pump can be switched to confluence or single mode freely by the command of the digital input signal DIN5 from the main machine.

No.	Symbol	Name	Range	Factory default value
H47	DL_L	Pump confluence signal switching	0 : Confluence when the signal is OFF 1 : Confluence when the signal is ON	1
H54 *	P_C_	Pump switching condition	0 : Digital input switching 1 : Autonomous switching	0

\* The changed parameter will be applied, when turn ON the supply power again.

By setting the parameter "H47: Pump confluence signal switching", the input logic of the confluence / single mode determined by the digital input signal DIN5 can be set.

H47 (DL_L) : Pump confluence signal switching	DIN5: Pump capacity switching input	Pump State	DOUT3: Pump capacity switching output
0	OFF	Confluence	OFF
	ON	Single	ON
1	OFF	Single	OFF
	ON	Confluence	ON

## Chapter 14 Maintenance and Inspection


### 14.1 Protective Functions

#### 14.1.1 Description of alarms


If any of the protective functions is activated, the corresponding alarm is output, and the following alarm code is displayed on the LED display of the operation panel.

When an alarm is output, the pump stops. Depending on the condition, the contact output is switched as follows:

(Normal condition)



(During alarm output)



If any of the protective functions is activated, conduct inspections according to the table below to remove the cause of the alarm and take corrective actions.

To reset the alarm condition, perform the following procedure:

- Turn OFF the power supply once, and then turn it ON again.

Alarm code	Name	Cause	Corrective action					
E10	Output device error  The output device overcurrent protection is activated.	The motor rotation speed is unstable due to contamination.	• Replace the motor pump and hydraulic oil.					
		The pump started in the reverse rotating direction due to return of load volume.	• Reduce the load volume. • Review the startup timing.					
		The pump is running under vacuum due to excessive load of inertial, resulting in out-of-control condition.	• Review the hydraulic circuit. • Reduce the load of inertial.					
		The pump or motor has been stuck up or locked.	• Replace the motor or the pump.					
		Short-circuit or ground fault of the motor	• Replace the motor.					
		Fault of the encoder	• Replace the motor.					
		Fault of the controller	• Replace the controller.					
		Operation error due to excessive noise	• Reduce ambient noise. • Review the wiring. • Insert a ferrite core.					
E11	Instantaneous overcurrent  The motor output current is higher than the specified value.	The motor rotation speed is unstable due to contamination.	• Replace the pump and hydraulic oil.					
		The pump started in the reverse rotating direction due to return of load volume.	• Reduce the load volume. • Review the startup timing.					
		The pump is running under vacuum due to excessive load of inertial, resulting in out-of-control condition.	• Review the hydraulic circuit. • Reduce the load of inertial.					
		The pump or motor has been stuck up or locked.	• Replace the motor or the pump.					
	<table border="1"> <thead> <tr> <th>SUT00D</th> <th>Specified value</th> </tr> </thead> <tbody> <tr> <td>8021-10-B</td> <td>110Apeak</td> </tr> <tr> <td>8021-10YB</td> <td>60Apeak</td> </tr> </tbody> </table>	SUT00D	Specified value	8021-10-B	110Apeak	8021-10YB	60Apeak	
SUT00D	Specified value							
8021-10-B	110Apeak							
8021-10YB	60Apeak							

Alarm code	Name		Cause	Corrective action
	13021-10-B 15021-10-B	240Apeak	Short-circuit or ground fault of the motor	• Replace the motor.
	13021-10YB 15021-10YB	120Apeak	Fault of the encoder	• Replace the motor.
			Fault of the controller	• Replace the controller.
			Operation error due to excessive noise	• Reduce ambient noise. • Review the wiring. • Insert a ferrite core.
E12	<b>Overspeed</b>		The pump is running in the reverse rotating direction at high speed due to return of load volume.	• Reduce the load volume.
	The motor rotation speed is higher than the specified value (120% of the maximum rotation speed).		The pump is running under vacuum at high speed due to excessive load of inertial.	• Review the hydraulic circuit. • Reduce the load of inertial.
	SUT00D	Specified value	Fault of the encoder	• Replace the motor.
	8021	3240min <sup>-1</sup>		
	13021 15021	3720min <sup>-1</sup>		
E13	<b>Regenerative brake overcurrent</b>		The regenerative resistor is short-circuited.	• Replace the regenerative resistor.
	The regenerative current is higher than the specified value.		The regenerative resistor's resistance is too small.	• Check the resistance of the regenerative resistor.
			Regenerative energy of the motor is too large.	• Extend the acceleration/deceleration time. • Reduce the load.
E14	<b>Regenerative brake overload</b>		The regenerative energy is too large relative to the capacity of the regenerative resistor connected.	• Review the capacity of the regenerative resistor. • Extend the acceleration/deceleration time. • Reduce the load. • Review the operation cycle.
	The regenerative resistor's overload protection is activated. The overload protection is activated at elapse of a specified time after "n09: Regenerative load ratio" exceeds the specified value (25%).		Incorrect setting of "P25: Regenerative resistance value" or "P26: Regenerative resistance capacity"	• Check the set value.
			The power feed voltage is too high.	• Measure the power feed voltage, and set the voltage in the specified range.
E15	<b>Undervoltage</b>		The power supply voltage is low.	• Set the power supply voltage at the specified value.
	The main circuit DC voltage is lower than the specified value (under any of the following conditions).		Fault of the controller	• Replace the controller.

Alarm code	Name	Cause	Corrective action								
	<p>○200V</p> <table border="1"> <thead> <tr> <th>Specified value</th> <th>Power supply voltage conversion value</th> </tr> </thead> <tbody> <tr> <td>DC190V or less:21ms DC150V VDC or less: Instantaneously</td> <td>AC134V or less AC106V or less</td> </tr> </tbody> </table> <p>○400V</p> <table border="1"> <thead> <tr> <th>Specified value</th> <th>Power supply voltage conversion value</th> </tr> </thead> <tbody> <tr> <td>DC380V or less:21ms DC300V or less: Instantaneously</td> <td>AC269V or less AC212V or less</td> </tr> </tbody> </table>	Specified value	Power supply voltage conversion value	DC190V or less:21ms DC150V VDC or less: Instantaneously	AC134V or less AC106V or less	Specified value	Power supply voltage conversion value	DC380V or less:21ms DC300V or less: Instantaneously	AC269V or less AC212V or less		
Specified value	Power supply voltage conversion value										
DC190V or less:21ms DC150V VDC or less: Instantaneously	AC134V or less AC106V or less										
Specified value	Power supply voltage conversion value										
DC380V or less:21ms DC300V or less: Instantaneously	AC269V or less AC212V or less										
E16	<p><b>Overvoltage</b></p> <p>○200V The main circuit DC voltage is higher than the specified value of 400 VDC (power supply voltage conversion: 282 VAC).</p> <p>○400V The main circuit DC voltage is higher than the specified value of 800 VDC (power supply voltage conversion: 566 VAC).</p>	<p>The power supply voltage is high.</p> <p>No connection or incorrect connection of regenerative resistor, or large resistance</p> <p>Increased regenerative power due to rapid deceleration</p>	<ul style="list-style-type: none"> <li>Set the power supply voltage at the specified value.</li> <li>Connect a regenerative resistor.</li> <li>Review the wiring.</li> <li>Extend the deceleration time.</li> <li>Reduce the load of inertial.</li> </ul>								
E17	<p><b>Motor electronic thermal</b></p> <p>The motor overload protection is activated due to electronic thermal error.</p> <p>The motor overload protection is activated when “n11: Motor electronic thermal load ratio” exceeds the specified value (110%).</p>	<p>The operation duty ratio is high.</p> <p>The load pressure is high.</p> <p>Increased leak in the hydraulic circuit</p> <p>Increased current due to pump stuck-up</p> <p>Fault of the encoder</p>	<ul style="list-style-type: none"> <li>Extend the stop time.</li> <li>Review the operation duty ratio.</li> <li>Extend the acceleration/deceleration time.</li> <li>Review the hydraulic circuit.</li> <li>Check for an external leak in hydraulic piping, etc.</li> <li>Conduct cylinder maintenance. (Replace the packing, etc.)</li> <li>Replace the cylinder.</li> <li>Replace the pump.</li> <li>Replace the motor.</li> </ul>								
E18	<p><b>Magnetic pole detection error</b></p> <p>Magnetic pole detection is not completed within the specified time.</p>	<p>Stuck-up pump</p> <p>Incorrect wiring of the motor</p> <p>Incorrect wiring of the encoder</p> <p>Fault of the encoder</p> <p>Fault of the motor</p> <p>Fault of the controller</p>	<ul style="list-style-type: none"> <li>Replace the pump and hydraulic oil.</li> <li>Review the wiring.</li> <li>Replace the motor</li> <li>Replace the controller.</li> </ul>								
E20	<p><b>Encoder wiring disconnection</b></p> <p>The encoder wiring is disconnected.</p>	<p>Disconnection of encoder wiring</p> <p>Fault of the encoder</p> <p>Fault of the motor</p> <p>Fault of the controller</p>	<ul style="list-style-type: none"> <li>Review the wiring.</li> <li>Replace the motor.</li> <li>Replace the controller.</li> </ul>								

Alarm code	Name	Cause	Corrective action				
E21	Motor wiring disconnection	Disconnection or incorrect wiring of the motor	• Review the wiring.				
	The motor wiring is disconnected.	Fault of the output device	• Replace the controller.				
E24	Power supply open phase	Disconnection or contact failure of the power supply wiring	• Check the power supply wiring.				
	The power supply, U, V or W phase is open.						
E27	Controller electronic thermal	The operation duty ratio is high.	• Extend the stop time. • Review the operation duty ratio.				
	The controller overload protection is activated due to electronic thermal error. The controller overload protection is activated when “n12: Controller electronic thermal load ratio” exceeds the specified value (120%).	The load pressure is high.	• Review the hydraulic circuit.				
E28	Short-time over rating	The operation duty ratio is high.	• Extend the stop time. • Review the operation duty ratio.				
	Overload protection is activated because short-time operation rating is exceeded.	The load pressure is high.	• Review the hydraulic circuit.				
		Increased leak in the hydraulic circuit	• Check for an external leak in hydraulic piping, etc. • Conduct cylinder maintenance. (Replace the packing, etc.) • Replace the cylinder.				
E30	Pressure sensor error	Incorrect wiring of the pressure sensor harness	• Check the wiring.				
	The pump pressure sensor is disconnected or short-circuited, or abnormal pressure is detected.	Disconnection, short-circuit or contact failure of the pressure sensor harness	• Check the pressure sensor harness. • Replace the pressure sensor harness.				
		Detection of abnormal pressure	• Review the hydraulic circuit.				
		Fault of the pressure sensor	• Replace the pressure sensor.				
E31	Motor startup error	Incorrect connections of the U, V, and W phases of the motor wiring	• Check the motor wiring.				
	The motor rotating direction is different from the command for 2 seconds or longer.	“P15: Bias pressure” is set at “0”, and the command from the main machine is “0”.	• Adjust the setting of “P15: Bias pressure”. • Set a bias pressure with the main machine.				
E40	Motor thermistor wiring disconnection/short-circuit	Incorrect wiring of the motor thermistor	• Review the wiring.				
	The motor thermistor is disconnected or short-circuited.	Disconnection or short-circuit of the motor thermistor wiring					
		Contact failure of the motor thermistor wiring					
		Fault of the motor thermistor	• Replace the motor.				
E41	Motor temperature rise error	The motor cooling fan has stopped.	• Check the fan power supply connection. • Replace the motor cooling fan.				
	The motor temperature is higher than the specified value for 2 seconds or longer.	The ambient temperature is high.	• Install the unit in a place where ambient temperature is within the specified range. • Install the unit in a well-ventilated place.				
<table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>SUT00D</td> <td>Specified value</td> </tr> <tr> <td>8021</td> <td>145°C</td> </tr> </table>		SUT00D	Specified value	8021	145°C		
SUT00D	Specified value						
8021	145°C						

Alarm code	Name		Cause	Corrective action								
	13021 15021	140°C	The operation duty ratio is high.	<ul style="list-style-type: none"> <li>Extend the stop time.</li> <li>Review the operation duty ratio.</li> </ul>								
			The load pressure is high.	<ul style="list-style-type: none"> <li>Review the hydraulic circuit.</li> </ul>								
E42	Radiator fin thermistor disconnection  The radiator fin thermistor is disconnected or short-circuited		Disconnection or short-circuit of the radiator fin thermistor wiring	<ul style="list-style-type: none"> <li>Replace the controller.</li> </ul>								
			Contact failure of the radiator fin thermistor wiring.									
E43	Radiator fin temperature rise error  The radiator fin temperature is higher than the specified value for 30 seconds or longer.		The ambient temperature is high.	<ul style="list-style-type: none"> <li>Install the unit in a place where ambient temperature is within the specified range.</li> <li>Install the unit in a well-ventilated place.</li> </ul>								
	<table border="1"> <thead> <tr> <th>SUT00D</th> <th>規程値</th> </tr> </thead> <tbody> <tr> <td>8021</td> <td>75°C</td> </tr> <tr> <td>13021-10YB 15021-10YB</td> <td>75°C</td> </tr> <tr> <td>13021-10-B 15021-10-B</td> <td>85°C</td> </tr> </tbody> </table>		SUT00D		規程値	8021	75°C	13021-10YB 15021-10YB	75°C	13021-10-B 15021-10-B	85°C	The operation duty ratio is high.
SUT00D	規程値											
8021	75°C											
13021-10YB 15021-10YB	75°C											
13021-10-B 15021-10-B	85°C											
			The load pressure is high.	<ul style="list-style-type: none"> <li>Review the hydraulic circuit.</li> </ul>								
E64	Dry operation error  The pump started with a low oil level.		The oil level is low.	<ul style="list-style-type: none"> <li>Refill hydraulic oil.</li> </ul>								
			Air release failure	<ul style="list-style-type: none"> <li>Release air.</li> </ul>								

#### 14.1.2 Description of warnings

When a warning condition occurs, the following warning code appears on the LED display of the operation panel.

At occurrence of a warning condition indicated with (\*) in the table below, “DO4: Digital output 4” turns ON. When the warning condition is reset, DO4 turns OFF.

<b>IMPORTANT</b>	If you keep operating the unit regardless of a warning condition, the protective function is activated to output an alarm.
------------------	--

Warning code	Name	Cause	Corrective action						
L44	Motor temperature abnormal warning  The motor temperature is higher than the specified value.	The motor cooling fan has stopped.	<ul style="list-style-type: none"> <li>Check the wiring.</li> <li>Replace the motor cooling fan.</li> </ul>						
		The ambient temperature is high.	<ul style="list-style-type: none"> <li>Install the unit in a place where ambient temperature is within the specified range.</li> <li>Install the unit in a well-ventilated place.</li> </ul>						
	<table border="1"> <thead> <tr> <th>SUT00D</th> <th>規程値</th> </tr> </thead> <tbody> <tr> <td>8021</td> <td>143°C-2sec</td> </tr> <tr> <td>13021 15021</td> <td>138°C-2sec</td> </tr> </tbody> </table>	SUT00D	規程値	8021	143°C-2sec	13021 15021	138°C-2sec	The operation duty ratio is high.	<ul style="list-style-type: none"> <li>Extend the stop time.</li> <li>Review the operation duty ratio.</li> </ul>
SUT00D	規程値								
8021	143°C-2sec								
13021 15021	138°C-2sec								
		The load pressure is high.	<ul style="list-style-type: none"> <li>Review the hydraulic circuit.</li> </ul>						


Warning code	Name	Cause	Corrective action								
L45	<b>Radiator fin temperature abnormal warning</b>  The radiator fin temperature is higher than the specified value  <table border="1"> <thead> <tr> <th>SUT00D</th> <th>規程値</th> </tr> </thead> <tbody> <tr> <td>8021</td> <td>73°C-10sec</td> </tr> <tr> <td>13021-10YB 15021-10YB</td> <td>73°C-10sec</td> </tr> <tr> <td>13021-10-B 15021-10-B</td> <td>83°C-10sec</td> </tr> </tbody> </table>	SUT00D	規程値	8021	73°C-10sec	13021-10YB 15021-10YB	73°C-10sec	13021-10-B 15021-10-B	83°C-10sec	The ambient temperature is high.	<ul style="list-style-type: none"> <li>• Install the unit in a place where ambient temperature is within the specified range.</li> <li>• Install the unit in a well-ventilated place.</li> </ul>
		SUT00D	規程値								
		8021	73°C-10sec								
		13021-10YB 15021-10YB	73°C-10sec								
13021-10-B 15021-10-B	83°C-10sec										
The operation duty ratio is high.	<ul style="list-style-type: none"> <li>• Extend the stop time.</li> <li>• Review the operation duty ratio.</li> </ul>										
The load pressure is high.	<ul style="list-style-type: none"> <li>• Review the hydraulic circuit.</li> </ul>										
L49 (*1)	<b>Overload warning</b>  “n11: Motor electronic thermal load ratio” or “n12: Controller electronic thermal load ratio” is higher than “P29: Overload warning output judgment level”.	The operation duty ratio is high.	<ul style="list-style-type: none"> <li>• Extend the stop time.</li> <li>• Review the operation duty ratio.</li> </ul>								
		The “P29: Overload warning output judgment level” setting is low.	<ul style="list-style-type: none"> <li>• Review the parameter setting.</li> </ul>								
L50	<b>Power supply voltage drop warning</b> ○200V The main circuit DC voltage is lower than the specified value 240 VDC, (Power supply voltage conversion: 170 VAC, for 2 seconds). ○400V The main circuit DC voltage is lower than the specified value 430 VDC, (Power supply voltage conversion: 304 VAC, for 2 seconds).	The power supply voltage is low.	<ul style="list-style-type: none"> <li>• Set the power supply voltage at the specified value.</li> </ul>								
		Fault of the controller	<ul style="list-style-type: none"> <li>• Replace the controller.</li> </ul>								
L60	<b>Pressure error warning</b>  Control pressure cannot increase to a target pressure due to low output torque, resulting in current command saturation.	The power supply voltage is low.	<ul style="list-style-type: none"> <li>• Set the power supply voltage at the specified value.</li> </ul>								
		Fault of the encoder	<ul style="list-style-type: none"> <li>• Replace the controller.</li> </ul>								

(\*1) When the warning occurs, “DO4: Digital Output 4” will be ON. It will become to OFF if the warning is released.

### 14.1.3 Contact Output at Power-ON

When the power supply is turned ON, the contact output is as follows:

Prepare such a sequence that the main machine does not detect an alarm condition until initialization is completed after the power supply is turned ON.





\*1. Initialization time at ambient temperature of approx. 15°C.


When the ambient temperature is lower than 15°C, the system increases the initialization time (up to 15 seconds, when the ambient temperature is 0°C).

\*2. The above example shows control stop signal ON/OFF status in a case where the “P00” (Start/stop signal switching) parameter is set at “0”. To start/stop the unit with the control stop signal, input the signal after the ready signal turns ON. With a system combining two or more units, the main unit should be set in control status first, and then the sub unit should be set in control status.

14.1.4 Troubleshooting







## 14.2 Periodic Inspection



- To conduct inspection work, wear protective goggles and globes, and turn OFF the power supply.
- During air blowing, be careful that foreign objects will not touch your eyes.
- When disassembling the unit, be careful about oil running out of the piping. Before inspection, make sure that there is no residual pressure in the piping.
- If hydraulic oil remaining in the cylinder and piping returns to the tank, it may overflow out of the tank. Do not return hydraulic oil from the cylinder into the tank. Collect the hydraulic oil separately with an oil pan etc.
- Check for abnormal sound, abnormal vibration or abnormal heating from the product.

Inspection part/item	Inspection cycle	Inspection method
◆ Hydraulic oil <ul style="list-style-type: none"> <li>● Oil level check</li> <li>● Oil temperature check</li> <li>● Oil color check</li> </ul>	<ul style="list-style-type: none"> <li>● Occasionally</li> <li>● Occasionally</li> <li>● Semiannually</li> </ul>	<ul style="list-style-type: none"> <li>● Make sure that hydraulic oil is filled to the specified level. Check for whitish muddiness and air bubbles in hydraulic oil.</li> <li>● Make sure that the oil temperature is 60°C or lower. (Normally, the hydraulic oil operating temperature range is 15 to 50°C.)</li> <li>● Deterioration of hydraulic oil can be checked by color. If hydraulic oil turns brownish (ASTM level L4: bright yellow), replace the oil.</li> <li>* For specifications of hydraulic oil, see “3.2 Specifications”.</li> </ul>
◆ Motor cooling fan ◆ Motor body	<ul style="list-style-type: none"> <li>● Monthly</li> <li>● Monthly</li> </ul>	<ul style="list-style-type: none"> <li>● Check if the cooling fan is normally rotating. Check for dust in the fan.</li> <li>● If the fan is clogged with much dust, cooling effect deteriorates. Clean the fan.</li> <li>● Check if the ambient temperature is not too high.</li> </ul>
◆ Controller	<ul style="list-style-type: none"> <li>● Monthly</li> </ul>	<ul style="list-style-type: none"> <li>● Check for dust in the air inlet port at the bottom of the controller.</li> <li>● Check for dust in the cooling fan at the top of the controller.</li> <li>● Check if the ambient temperature is not too high.</li> </ul>
◆ Electrical wiring	<ul style="list-style-type: none"> <li>● Semiannually</li> </ul>	<ul style="list-style-type: none"> <li>● Check the cable sheath for a crack or damage.</li> <li>● Measure the insulation resistance to check for insulation resistance reduction.</li> <li>● Make sure that the ground cable is securely connected.</li> </ul>
◆ Gear pump	<ul style="list-style-type: none"> <li>● Occasionally</li> </ul>	<ul style="list-style-type: none"> <li>● If oil leaks from the oil seal, replace the pump. The leak oil will be drained through the oil groove on the motor side. Check for oil leak.</li> </ul>
◆ Screws and pipes ◆ Hoses	<ul style="list-style-type: none"> <li>● Occasionally</li> <li>● Occasionally</li> </ul>	<ul style="list-style-type: none"> <li>● Check screws and pipes for looseness and oil leak.</li> <li>● Check hoses for a crack, damage or flaw.</li> </ul>

- During operation, be careful not to access or touch a rotating part (e.g. motor cooling fan).
- To access inside of the controller, observe the following procedure to prevent electric shock.
  - 1) Turn OFF the main power supply for the controller. Turn OFF the power supply breaker for all power supply circuits of the molding machine. To ensure safety, post an “Do Not Operate (During Maintenance)” sign on the power supply breaker, so that the unit will not be accidentally operated during maintenance.

- 2) Before you access terminals, wait for at least 5 minutes after turning OFF the controller power supply. The controller uses a large-capacitance capacitor. If you work with the capacitor charged, you may get electric shock. Be sure to leave the controller for 5 minutes or longer (to discharge electricity from the capacitor) before you touch or disconnect the terminals.
- 3) To restart the unit, mount all covers to the live parts (terminals in the controller, etc.) before turning ON the power supply.

## 14.3 Cleaning and Replacement

### 14.3.1 Replacement of oil

Replace hydraulic oil periodically. If the oil is used without replacement for a long period, it will adversely affect operation and service life of the hydraulic equipment and pump.

### 14.3.2 Cleaning of motor cooling fan

Check rotation of the motor cooling fan and the controller cooling fan. Periodically clear dust off the covers and fan surfaces.

### 14.3.3 Replacement of the controller

The controller parameters may have been changed from the default settings for the purpose of response gain adjustment and so on. In this case, when the controller is replaced with a spare, the controller's parameter settings are different from those of the original controller, so that the molding machine will not be restored to the original condition. The default parameter settings of the molding machine should be kept by the user. After replacement of the controller, change the parameters to the original settings.

Note: Parameters "H21" to "H28" are specific to each controller. Do not change these parameters of a new controller.

The parameters of flow rate correction ratio "H15" (Q\_EV), pressure sensor gain "H30" (PS\_G) and flow rate command scaling value "P07" (QMAX) have been set for operation with a pair of pump and controller before shipment. Therefore, these parameters are not matched with those of the spare controller. You must register the original controller's "H15" (Q\_EV), "H30" (PS\_G) and "P07" (QMAX) settings in the new controller after replacement.

### 14.3.4 Replacement of the pressure sensor

After the pressure sensor of the pump unit is replaced, the pressure sensor gain setting should be changed with the "H30" (PS\_G) parameter.

- 1) In the pressure control mode, set "Pi" at "10.0 V" (= PMAX) or a highest allowable pressure value.
- 2) While checking the control pressure with a pressure gauge (high-precision pressure gauge), adjust the "H30" parameter so that the control pressure becomes equal to PMAX or the specified pressure value.
- 3) For pressure sensor zero-point adjustment, turn OFF the controller power supply, and after confirming pressure reduction, turn ON the power supply again. Then, the pressure sensor zero point will be automatically corrected. Perform this procedure before pressure gain adjustment.

### 14.3.5 Replacement of the pump

After replacement of the pump, the settings of flow rate correction ratio “H15” (Q\_EV) and flow rate command scaling value “P07” (QMAX) should be changed.

- If a pressure increase error occurs with the small flow rate setting after pump replacement, re-adjust the flow rate correction ratio “H15” (Q\_EV).
  - 1) Run the unit in the pressure control mode for (injection) cylinder end.
  - 2) Enter “10 V” (99.9%) for the pressure command, and enter “0.05 V” [0.1 V] (1%) for the flow rate command.
  - 3) Adjust the “H15” (Q\_EV) parameter so that the pressure increases to the maximum value (PMAX) with the pressure gauge.
- If a speed error (over speed or under speed error) occurs with the maximum flow rate setting after pump replacement, re-adjust the flow rate command scaling value “P07” (QMAX).
  - 1) While running the main machine in the measurement mode, perform the following adjustment.
  - 2) Enter “10 V” (99.9%) for the pressure command.
  - 3) Increase the flow rate command, and run the measurement motor.
  - 4) While monitoring the “n04 (Qo)” value in the monitor mode, make sure that the monitor value conforms to the flow rate command voltage.  
(Make sure that the monitor value is not in the power control range or override range.)
  - 5) Adjust the “P07” (QMAX) parameter so that the flow rate value based on the measurement motor rotation speed is equal to the original value before replacement.









● SUT00D8021-21YB-N0324 category C3

ELECTRICAL COMPONENTS (OPTIONAL)

NAME	TYPE	NUMBER
DC REACTOR	PW-SOP04	1
REGENERATIVE BRAKING RESISTOR(2)*2		
ENCODER HARNESS	PW-SNF06 PW-SR001 PW-FC01	1 3 1
PRESSURE SENSOR HARNESS(INCLUDING A RING CORE)		
NOISE FILTER		
FERRITE CORE		

Note\*1 EMC Compliant Options: Please prepare these components (\*1) to comply with the EMC standard.  
 Note\*2 Please prepare a terminal block on the main machine side for connection of 2 regenerative braking resistors in parallel. Please use the 2mm<sup>2</sup> VCI cable or 1.5mm<sup>2</sup> CE cable, and make sure the cable length is less than 1m.

<REFERENCE>INSTALLING DIMENSIONS



SENSOR HARNESS SPECIFICATION (The length must be within 5m when manufacturing)

NAME	TERMINATE SPECIFICATION		CABLE SPECIFICATION		FERRITE CORE (RECOMMENDATION)
	SUT MOTOR-PUMP	CONTROLLER SIDE	CABLE TYPE	DIAMETER	
ENCODER CABLE (TYPE : PW-SH05-P27-100R)	CONTACT 170366-1	VINI INSULATION RING TYPE TERMINAL (RAV1, 25-3)	KYC-36SB (4 PAIR-SHIELDED CABLE) (WITH DRAIN-WIRE)	AWG22	NOT NECESSARY
	HOUSING (MADE BY AMP)			5m	
PRESSURE SENSOR CABLE (TYPE : PW-SPH05-001)	CONTACT 171630-1	VINI INSULATION RING TYPE TERMINAL (RAV1, 25-3)	KYC-36SB (3 CORES-SHIELDED) (CABLE WITH DRAIN-WIRE)	AWG20	MADE BY KITAGAWA INDUSTRIES RFC-10
	RUBBER PLUG HOUSING DOUBLE LOCK PLATE (MADE BY AMP)			5m	



● SUT00D13021-10-B-N0321 / SUT00D15021-10-B-N0365

ELECTRICAL COMPONENTS (OPTIONAL)

NAME	TYPE	NUMBER
DC REACTOR	*1	1
REGENERATIVE BRAKING RESISTOR(G)*2		
ENCODER HARNESS		
PRESSURE SENSOR HARNESS(INCLUDING A RING CORE)		
NOISE FILTER		
RING CORE1		
RING CORE2	*2	2
FERRITE CORE1		
FERRITE CORE2		
FERRITE CORE3		

Note\*1 EMC Compliant Options: Please prepare these components (\*1) to comply with the EMC standard.  
 Note\*2 Please prepare a terminal block on the main machine side for connection of 6 regenerative braking resistors in parallel, and make the wire length as short as possible.

<REFERENCE> INSTALLING DIMENSIONS



SENSOR HARNESS SPECIFICATION (The length must be within 5m when manufacturing)

NAME	TERMINATE SPECIFICATION		CABLE SPECIFICATION		RING CORE (RECOMMENDATION)		
	SUT MOTOR-PUMP	CONTROLLER SIDE	CABLE TYPE	DIAMETER			
ENCODER CABLE (TYPE : PM-SC005-P22-409R)	CONTACT HOUSING (TYCO ELECTRONICS 60-MADE)	170366-1	172169-1	KVC-36SB (4 PAIR-SHIELDED CABLE) (WITH DRAIN-WIRE)	AWG22	5m	NOT NECESSARY
	CONTACT RUBBER PLUG HOUSING (TYCO ELECTRONICS 60-MADE)	171630-1	172746-1	KVC-36SB (3 CORES-SHIELDED CABLE WITH DRAIN-WIRE)	AWG20	5m	RING CORE1 (TYPE : PM-SC001)
PRESSURE SENSOR CABLE (TYPE : PM-SP005-003 (WITH RING CORE1))	CONTACT RUBBER PLUG HOUSING (TYCO ELECTRONICS 60-MADE)	171630-1	172746-1	KVC-36SB (3 CORES-SHIELDED CABLE WITH DRAIN-WIRE)	AWG20	5m	RING CORE1 (TYPE : PM-SC001)
	DOUBLE LOCK PLATE (TYCO ELECTRONICS 60-MADE)	174357-2	174357-2	KVC-36SB (3 CORES-SHIELDED CABLE WITH DRAIN-WIRE)	AWG20	5m	RING CORE1 (TYPE : PM-SC001)

